

VIPA System 300V



SM | Manual HB130E_SM | Rev. 10/10 March 2010



Copyright © VIPA GmbH. All Rights Reserved.

This document contains proprietary information of VIPA and is not to be disclosed or used except in accordance with applicable agreements.

This material is protected by the copyright laws. It may not be reproduced, distributed, or altered in any fashion by any entity (either internal or external to VIPA), except in accordance with applicable agreements, contracts or licensing, without the express written consent of VIPA and the business management owner of the material.

For permission to reproduce or distribute, please contact: VIPA, Gesellschaft für Visualisierung und Prozessautomatisierung mbH Ohmstraße 4, D-91074 Herzogenaurach, Germany Tel.: +49 (91 32) 744 -0 Fax.: +49 9132 744 1864 EMail: info@vipa.de http://www.vipa.de

Note

Every effort has been made to ensure that the information contained in this document was complete and accurate at the time of publishing. Nevertheless, the authors retain the right to modify the information. This customer document describes all the hardware units and functions known at the present time. Descriptions may be included for units which are not present at the customer site. The exact scope of delivery is described in the respective purchase contract.

CE Conformity

Hereby, VIPA GmbH declares that the products and systems are in compliance with the essential requirements and other relevant provisions of the following directives:

- 2004/108/EC Electromagnetic Compatibility Directive
- 2006/95/EC Low Voltage Directive

Conformity is indicated by the CE marking affixed to the product.

Conformity Information

For more information regarding CE marking and Declaration of Conformity (DoC), please contact your local VIPA customer service organization.

Trademarks

VIPA, SLIO, System 100V, System 200V, System 300V, System 300S, System 400V, System 500S and Commander Compact are registered trademarks of VIPA Gesellschaft für Visualisierung und Prozessautomatisierung mbH.

SPEED7 is a registered trademark of profichip GmbH.

SIMATIC, STEP, SINEC, S7-300 and S7-400 are registered trademarks of Siemens AG.

Microsoft und Windows are registered trademarks of Microsoft Inc., USA.

Portable Document Format (PDF) and Postscript are registered trademarks of Adobe Systems, Inc.

All other trademarks, logos and service or product marks specified herein are owned by their respective companies.

Information product support

Contact your local VIPA Customer Service Organization representative if you wish to report errors or questions regarding the contents of this document. If you are unable to locate a customer service center, contact VIPA as follows:

VIPA GmbH, Ohmstraße 4, 91074 Herzogenaurach, Germany

Telefax:+49 9132 744 1204 EMail: documentation@vipa.de

Technical support

Contact your local VIPA Customer Service Organization representative if you encounter problems with the product or have questions regarding the product. If you are unable to locate a customer service center, contact VIPA as follows:

VIPA GmbH, Ohmstraße 4, 91074 Herzogenaurach, Germany

Telephone: +49 9132 744 1150/1180 (Hotline) EMail: support@vipa.de

Contents

About this manual1			
Safety information			
Chapter 1	Basics	1-1	
Safety Info	rmation for Users	1-2	
General de	scription of the System 300V	1-3	
Componen	ts	1-4	
Chapter 2	Assembly and installation guidelines	2-1	
Overview		2-2	
Installation	dimensions	2-3	
Installation	at the profile rail	2-4	
Cabling			
Installation	Guidelines	2-10	
Chapter 3	Digital Input Modules	3-1	
System over	erview		
321-1BH01	- DI 16xDC 24V	3-3	
321-1BL00	- DI 32xDC 24V	3-5	
321-1FH00) - DI 16xAC120/230V		
Chapter 4	Digital Output Modules	4-1	
System ove	erview		
322-1BF01	- DO 8xDC 24V 2A	4-4	
322-1BH01	- DO 16xDC 24V 1A		
322-1BH41	- DO 16xDC 24V 2A		
322-1BH60) - DO 16xDC 24V 0.5A for manual operation	4-10	
322-1BL00	- DO 32xDC 24V 1A	4-13	
322-5FF00 - DO 8xAC 120/230V 2A 4-16			
322-1HH00) - DO 16xRelay	4-21	
Chapter 5	Digital Input/Output Modules	5-1	
System over	erview	5-2	
Security hir	nts for DIO modules	5-2	
323-1BH00) - DIO 16xDC 24V 1A		
323-1BH01	- DI 8xDC 24V, DO 8xDC 24V 1A		
323-1BL00	- DI 16xDC 24V, DO 16xDC 24V 1A	5-7	
Chapter 6	Analog Input Modules	6-1	
System ove	erview	6-2	
Security hir	nt	6-2	
Parameteri	zation - Basics	6-4	
331-1KF01	- AI 8x13Bit		
331-1KF01	- AI 8x13Bit - Parameterization		
331-1KF01 - AI 8x13Bit - Technical Data			
331-7Kx01	- AI 8(2)x12Bit		
331-7Kx01	- AI 8(2)X12Bit - Parameterization	6-24	
331-7Kx01	- AI 8(2)x12Bit - Diagnostics	6-29	
331-7Kx01	- AI 8(2)x12Bit - Technical Data	6-35	

Chapter 7	Analog Output Modules	7-1
System ov	erview	7-2
Security hi	nt	7-2
Connecting	g loads and actuators	7-4
Analog val	ue representation	7-5
Parameter	ization - Basics	7-6
Diagnostic	S	7-9
332-5Hx01	1 - AO 2/4x12Bit U/I	7-13
332-5HDx(0 - AO 4x12Bit for manual operation	7-18
Chapter 8	Analog In/Output Modules	8-1
System ov	erview	
Security hi	nt	
General		
Analog val	ue representation	
Parameter	ization	
334-0KE00	0 - AI 4/AO 2x12Bit	
Appendix		A-1
Indov		A 1
muex		A-I

About this Manual

This manual describes the operation of the System 300V and the according available signal modules (SM). A short overview over the range of products is followed by a detailed description of the single modules. You will get information for connecting and operating the System 300V and the additional SM modules.

Overview Chapter 1: Basics

This introduction includes recommendations on the handling of the modules of the VIPA System 300V and introduces you to central res. decentral automation systems.

Chapter 2: Installation and assembly guide lines

All information that you need for installation and cabling of a PLC with components of the System 300V may be found in this chapter.

Chapter 3-5: Digital in-/output modules

These chapters introduce you to the digital peripheral modules of the System 300V from VIPA and contain all information that you will need for installation. Chapter 3 contains information about the digital input modules, chapter 4 describes the digital output modules and chapter 5 concerns to the combined input/output modules.

Chapter 6-8: Analog in-/output modules

Content of these chapters is the description of the analog peripheral modules of the System 300V from VIPA. Chapter 6 gives you all necessary information about the analog input, chapter 7 informs about the analog output and chapter 8 about the analog input/output modules.

Objective and contents	This manual describes the signal modules (SM) that can be used with the System 300. It contains a description of construction, project implementation and application of the products as well as the technical data.
Target audience	The manual is targeted at users who have a background in automation technology.
Structure of the manual	The manual consists of chapters. Every chapter provides a self-contained description of a specific topic.
Guide to the document	 The following guides are available in the manual: an overall table of contents at the beginning of the manual an overview of the topics for every chapter an index at the end of the manual.
Availability	 The manual is available in: printed form, on paper in electronic form as PDF-file (Adobe Acrobat Reader)
lcons Headings	Important passages in the text are highlighted by following icons and headings:
$\underline{\wedge}$	Danger! Immediate or likely danger. Personal injury is possible.
\triangle	Attention! Damages to property is likely if these warnings are not heeded.
	Note! Supplementary information and useful tips.

Safety information

Applications conforming with specifications The modules of the System 300V are constructed and produced for:

- all VIPA System 300 components
- communication and process control
- general control and automation applications
- industrial applications
- operation within the environmental conditions specified in the technical data
- installation into a cubicle



Danger!

This device is not certified for applications in

• in explosive environments (EX-zone)

Documentation

The manual must be available to all personnel in the

- project design department
- installation department
- commissioning
- operation



The following conditions must be met before using or commissioning the components described in this manual:

- Modification to the process control system should only be carried out when the system has been disconnected from power!
- Installation and modifications only by properly trained personnel
- The national rules and regulations of the respective country must be satisfied (installation, safety, EMC ...)

Disposal

National rules and regulations apply to the disposal of the unit!

Chapter 1 Basics

OutlineMain theme of this chapter is to give you an overview about the System
300V from VIPA. We will outline the possibilities of the installation of
central res. decentral systems.This chapter also contains general information about the System 300V like
measurements, hints for installation and the environmental conditions.

Content	Торіс		Page
	Chapter 1	Basics	1-1
	Safety Inform	nation for Users	
	General des	cription of the System 300V	1-3
	Components	5	1-4

Safety Information for Users

Handling of electrostatically sensitive modules VIPA modules make use of highly integrated components in MOS-Technology. These components are extremely sensitive to over-voltages that can occur during electrostatic discharges.

The following symbol is attached to modules that can be destroyed by electrostatic discharges.



The symbol is located on the module, the module rack or on packing material and it indicates the presence of electrostatically sensitive equipment. It is possible that electrostatically sensitive equipment is destroyed by energies and voltages that are far less than the human threshold of perception. These voltages can occur where persons do not discharge themselves before handling electrostatically sensitive modules and they can damage components thereby, causing the module to become inoperable or unusable. Modules, damaged in this way, are normally not immediately recognized. The according error may occur only after a while of operation.

Modules that have been damaged by electrostatic discharges can fail after a temperature change, mechanical shock or changes in the electrical load.

Only the consequent implementation of protection devices and meticulous attention to the applicable rules and regulations for handling the respective equipment can prevent failures of electrostatically sensitive modules.

Shipping of modules Modules must be shipped in the original packing material.

When you are conducting measurements on electrostatically sensitive modules you should take the following precautions:

• Floating instruments must be discharged before use.

• Instruments must be grounded.

Modifying electrostatically sensitive modules you should only use soldering irons with grounded tips.



Measurements and

alterations on

electrostatically

sensitive modules

Attention!

Personnel and instruments should be grounded when working on electrostatically sensitive modules.

General description of the System 300V

The System 300V The System 300V is a modular automation system for middle and high performance needs, that you can use either distributed or non-distributed. The single modules are directly clipped to a 530 mm backplane and are connected together with the help of bus clips at the backside.

The single modules of the VIPA System 300V are design compatible to Siemens. Due to the compatible backplane bus it is no problem to mix the modules from VIPA and Siemens.

The CPUs of the System 300V are instruction set compatible to S7-300 from Siemens. The CPUs are programmed via the VIPA programming software WinPLC7 or the SIMATIC manager from Siemens or other available programming tools.

The following picture illustrates the performance range of the System 300V:



Components

- The System 200V series consists of a number of PLC-CPUs. These are **Central system** programmed in STEP®7 from Siemens. Herefore you may use WinPLC7 from VIPA or the SIMATIC manager from Siemens. CPUs with integrated Ethernet interfaces or additional serial interfaces simplify the integration of the PLC into an existing network or the connection of additional peripheral equipment. The application program is saved in Flash or an additional plug-in memory module. Because of the automatic addressing, up to 32 peripheral modules can be called by the System 300V CPUs. In combination with a Profibus DP master and slave the PLC-CPUs or the **Decentral system** PC-CPU form the basis for a Profibus-DP network in accordance with DIN 19245-3. The DP network can be configured with the hardware configurator from Siemens. Together with the hardware configuration you transfer your project into the CPU via MPI. Another component of the decentral system is the CAN-Slave. It allows the link-up to the fieldbus system CANopen. A large number of peripheral modules are available from VIPA, for example Peripheral modules digital as well as analog inputs/outputs. These peripheral modules can be deployed central as well as decentral. **Dimensions**/ Profile rail 530mm Weight Peripheral modules with recessed labeling • Dimensions of the basic enclosure: 1tier width: (WxHxD) in mm: 40x125x120
- Installation

Please regard that the power supply and header modules like CPUs and couplers may only plugged-in at the left side.



2tier width: (WxHxD) in mm: 80x125x120 3tier width: (WxHxD) in mm: 120x125x120

Reliability	 Wiring by means of spring pressure connections (CageClamps) at the front connector Core cross-section 0.082.5mm² or 1.5 mm² Total isolation of the wiring at module change Potential separation of all modules to the backplane bus Burst/ESD acc. IEC 61000-4-2/IEC 61000-4-4 (up to level 3) Shock resistance acc. IEC 60068-2-6 / IEC 60068-2-27 (1G/12G)
Environmental conditions	 Operating temperature: 0 +60°C Storage temperature: -25 +70°C Relative humidity: 595% without condensation Ventilation by means of a fan is not required
Green Cable for project engineering	For project engineering of your DP slave you may transfer your projects from your PC to the CPU serial via MPI by using the "Green Cable". Please also regard the hints to the Green Cable in this chapter!
Integrated power supply	Every Profibus slave has an internal power supply. This power supply requires DC 24V. In addition to the electronics on the bus coupler, the supply voltage is also used to power any modules connected to the backplane bus. Please note that the maximum current that the integrated power supply can deliver to the backplane bus is 3.5A. The power supply is protected against reverse polarity and overcurrent.
Compatibility	The digital in-/output modules of the System 300V from VIPA are pin and function compatible to Siemens. The project engineering happens in the SIMATIC manager from Siemens.
	 Note! For programming of a System 300V CPU from VIPA please use always the CPU 315-2DP (6ES7 315-2AF03 V1.2) from Siemens in the hardware catalog. Please note the Profibus address 1 of the CPU 31x is system dependent reserved. For the project engineering, a thorough knowledge of the Siemens SIMATIC manager and the hardware configurator is required!

Chapter 2 Assembly and installation guidelines

Outline In this chapter you will find all information, required for the installation and the cabling of a process control with the components of the System 300V.

Content	Торіс		Page
	Chapter 2	Assembly and installation guidelines	2-1
	Overview.		2-2
	Installatior	n dimensions	2-3
	Installatior	at the profile rail	2-4
	Cabling		
	Installation	n Guidelines	2-10

Overview

General The single modules are directly installed on a profile rail and connected via the backplane bus coupler. Before installing the modules you have to clip the backplane bus coupler to the module from the backside.

The backplane bus coupler are included in the delivery of the peripheral modules.

Profile rail



Order number	А	В	С
VIPA 390-1AB60	160mm	140mm	10mm
VIPA 390-1AE80	482mm	466mm	8.3mm
VIPA 390-1AF30	530mm	500mm	15mm
VIPA 390-1AJ30	830mm	800mm	15mm
VIPA 390-9BC00*	2000mm	no Drillings	15mm

* Unit pack: 10 pieces

Bus connector For the communication between the modules the System 300V uses a backplane bus connector. The backplane bus connector are included in the delivering of the peripheral modules and are clipped at the module from behind before installing it to the profile rail.





Installation dimensions

Overview	Here follows all the important dimensions of the System 300V.		
Dimensions Basic enclosure	1tier width (WxHxD) in mm: 40 x 125 x 120 2tier width (WxHxD) in mm: 80 x 125 x 120 3tier width (WxHxD) in mm: 120 x 125 x 120		
Dimensions			
Installation dimensions	153mm 120mm 120mm U		

Installation at the profile rail

Structure:

You may install the System 300V as well horizontal as vertical. Please regard the allowed environment temperatures:

- horizontal structure: from 0 to 60°
- vertical structure: from 0 to 40°

The horizontal structure always starts at the left side with the power supply and the CPU, then you plug-in the peripheral modules beside to the right. You may plug-in maximum 32 peripheral modules to the CPU.



The vertical structure is turned for 90° against the clockwise direction.



Approach







- Bolt the profile rail with the background (screw size: M6), so that you still have minimum 65mm space above and 40mm below the profile rail.
- If the background is a grounded metal or device plate, please look for a low-impedance connection between profile rail and background.
- Connect the profile rail with the protected earth conductor. For this purpose there is a bolt with M6-thread.
- The minimum cross-section of the cable to the protected earth conductor has to be 10mm².
- Stick the power supply to the profile rail and pull it to the left side to the grounding bolt of the profile rail.
- Fix the power supply by screwing.
- Take a bus coupler and click it at the CPU from behind like shown in the picture.
- Stick the CPU to the profile rail right from the power supply and pull it to the power supply.
- Click the CPU downwards and bolt it like shown.
- Repeat this procedure with the peripheral modules, by clicking a backplane bus coupler, stick the module right from the modules you've already fixed, click it downwards and connect it with the backplane bus coupler of the last module and bolt it.



Danger!

- Before installing or overhauling the System 300V, the power supplies must be disconnected from voltage (pull the plug or remove the fuse)!
- Installation and modifications only by properly trained personnel!

Cabling

Overview

The power supplies and CPUs are exclusively delivered with CageClamp contacts. For the signal modules the front connectors are available from VIPA with screw contacts. In the following all connecting types of the power supplies, CPUs and input/output modules are described.

D

Danger!

- Before installation or overhauling, the power supplies must be disconnected from voltage (pull the plug or remove the fuse)!
- Installation and modifications only by properly trained personnel!

CageClamp technology (gray)

(1)

For the cabling of power supplies, bus couplers and parts of the CPU, gray connectors with CageClamp technology are used.

You may connect wires with a cross-section of 0.08mm² to 2.5mm². You can use flexible wires without end case as well as stiff wires.



- [1] Rectangular opening for screwdriver
- [2] Round opening for wires

The picture on the left side shows the cabling step by step from top view.

- To conduct a wire you plug a fitting screwdriver obliquely into the rectangular opening like shown in the picture.
- To open the contact spring you have to push the screwdriver in the opposite direction and hold it.
- Insert the insulation striped wire into the round opening. You may use wires with a cross-section from 0.08mm² to 2.5mm².
- By removing the screwdriver the wire is connected safely with the plug connector via a spring.



CageClamp technology (green)

(1)

For the cabling of e.g. the power supply of a CPU, green plugs with CageClamp technology are deployed.

Here also you may connect wires with a cross-section of 0.08mm² to 2.5mm². You can use flexible wires without end case as well as stiff wires.



- [1] Test point for 2mm test tip
- [2] Locking (orange) for screwdriver
- [3] Round opening for wires

The picture on the left side shows the cabling step by step from top view.

- For cabling you push the locking vertical to the inside with a suiting screwdriver and hold the screwdriver in this position.
- Insert the insulation striped wire into the round opening. You may use wires with a cross-section from 0.08mm² to 2.5mm².
- By removing the screwdriver the wire is connected safely with the plug connector via a spring.



Note!

In opposite to the gray connection clamp from above, the green connection clamp is realized as plug that can be clipped off carefully even if it is still cabled.



Front connectors
of the in-/output
modulesIn the following the cabling of the three variants of the front-facing
connector is shown:For the I/O modules the following plugs are available at VIPA:



continued ...

... continue



Installation Guidelines

General	The installation guidelines contain information about the interference free deployment of System 300V systems. There is the description of the ways, interference may occur in your control, how you can make sure the electromagnetic digestibility (EMC), and how you manage the isolation.
What means EMC?	Electromagnetic digestibility (EMC) means the ability of an electrical device, to function error free in an electromagnetic environment without being interferenced res. without interferencing the environment. All System 300V components are developed for the deployment in hard industrial environments and fulfill high demands on the EMC. Nevertheless you should project an EMC planning before installing the components and take conceivable interference causes into account.
Possible interference causes	 Electromagnetic interferences may interfere your control via different ways: Fields I/O signal conductors Bus system Current supply Protected earth conductor Depending on the spreading medium (lead bound or lead free) and the distance to the interference cause, interferences to your control occur by means of different coupling mechanisms. One differs: galvanic coupling capacitve coupling inductive coupling radiant coupling

Basic rules for In the most times it is enough to take care of some elementary rules to guarantee the EMC. Please regard the following basic rules when installing your PLC.

- Take care of a correct area-wide grounding of the inactive metal parts when installing your components.
 - Install a central connection between the ground and the protected earth conductor system.
 - Connect all inactive metal extensive and impedance-low.
 - Please try not to use aluminum parts. Aluminum is easily oxidizing and is therefore less suitable for grounding.
- When cabling, take care of the correct line routing.
 - Organize your cabling in line groups (high voltage, current supply, signal and data lines).
 - Always lay your high voltage lines and signal res. data lines in separate channels or bundles.
 - Route the signal and data lines as near as possible beside ground areas (e.g. suspension bars, metal rails, tin cabinet).
- Proof the correct fixing of the lead isolation.
 - Data lines must be laid isolated.
 - Analog lines must be laid isolated. When transmitting signals with small amplitudes the one sided laying of the isolation may be favorable.
 - Lay the line isolation extensively on a isolation/protected earth conductor rail directly after the cabinet entry and fix the isolation with cable clamps.
 - Make sure that the isolation/protected earth conductor rail is connected impedance-low with the cabinet.
 - Use metallic or metallized plug cases for isolated data lines.
- In special use cases you should appoint special EMC actions.
 - Wire all inductivities with erase links, that are not addressed by the System 300V modules.
 - For lightening cabinets you should prefer incandescent lamps and avoid luminescent lamps.
- Create an homogeneous reference potential and ground all electrical operating supplies when possible.
 - Please take care for the targeted employment of the grounding actions. The grounding of the PLC is a protection and functionality activity.
 - Connect installation parts and cabinets with the System 300V in star topology with the isolation/protected earth conductor system. So you avoid ground loops.
 - If potential differences between installation parts and cabinets occur, lay sufficiently dimensioned potential compensation lines.

Isolation of
conductorsElectrical, magnetical and electromagnetical interference fields are
weakened by means of an isolation, one talks of absorption.Via the isolation rail that is connected conductive with the rack

Via the isolation rail, that is connected conductive with the rack, interference currents are shunt via cable isolation to the ground. Hereby you have to make sure, that the connection to the protected earth conductor is impedance-low, because otherwise the interference currents may appear as interference cause.

When isolating cables you have to regard the following:

- If possible, use only cables with isolation tangle.
- The hiding power of the isolation should be higher than 80%.
- Normally you should always lay the isolation of cables on both sides. Only by means of the both-sided connection of the isolation you achieve a high quality interference suppression in the higher frequency area.

Only as exception you may also lay the isolation one-sided. Then you only achieve the absorption of the lower frequencies. A one-sided isolation connection may be convenient, if:

- the conduction of a potential compensating line is not possible
- analog signals (some mV res. µA) are transferred
- foil isolations (static isolations) are used.
- With data lines always use metallic or metallized plugs for serial couplings. Fix the isolation of the data line at the plug rack. Do not lay the isolation on the PIN 1 of the plug bar!
- At stationary operation it is convenient to deisolate the isolated cable interruption free and lay it on the isolation/protected earth conductor line.
- To fix the isolation tangles use cable clamps out of metal. The clamps must clasp the isolation extensively and have well contact.
- Lay the isolation on an isolation rail directly after the entry of the cable in the cabinet. Lead the isolation further on to the System 300V module and **don't** lay it on there again!



Please regard at installation!

At potential differences between the grounding points, there may be a compensation current via the isolation connected at both sides. Remedy: Potential compensation line

Chapter 3 Digital Input Modules

Outline This chapter contains a description of the structure and the operation of the VIPA digital input modules.

Content Topic Page Chapter 3 Digital Input Modules 3-1 System overview 3-2 321-1BH01 - DI 16xDC 24V 3-3 321-1BL00 - DI 32xDC 24V 3-5 321-1FH00 - DI 16xAC120/230V 3-7

System overview

Input Modules SM 321 In the following you find an overview over the digital input modules that are available at VIPA:



Order data Input modules

Туре	Order number	Page
DI 16xDC 24V	VIPA 321-1BH01	3-3
DI 32xDC 24V	VIPA 321-1BL00	3-5
DI 16xAC 120/230V	VIPA 321-1FH00	3-7

321-1BH01 - DI 16xDC 24V

Order data DI 16xDC 24V VIPA 321-1BH01

Description The digital input module collects the binary control signals from the process level and transmits them isolated to the superordinated bus system. It has 16 channels and their status is monitored via LEDs.

Properties

- 16 inputs, isolated to the backplane bus
- Nominal input voltage DC 24V
- Useable for switches and approximate switches
- Status monitoring of the channels via LED

Structure





.0

.1 .2 .3 .4

.6 .7

SM321

.0

.1

.2

.3

.4 .5

.6

.7

- [1] LEDs
- [2] flap with labeling strip
- [3] contact bar
- [4] flap opened with inner label

Pin assignment Circuit diagram Status monitor

Pin Assignment Circuit diagram



- LED Description
- .07 LEDs (green) I+0.0 to I+1.7 from ca. 15V on, the signal is recognized as "1" and the according LED is activated

Schematic diagram



Technical Data

Module name	VIPA 321-1BH01
Dimensions and weight	
Dimensions WxHxD	40x125x120mm
Weight	200g
Data for specific module	
Number of inputs	16
Programming specifications	
Input data	2byte
Voltages, Currents, Potentials	
Isolation	
 between channels and backplane bus 	yes
Isolation tested with	DC 500V
Current consumption	
- from the backplane bus	25mA
Power dissipation of the module	3.5W
Status, Interrupts, Diagnostics	
Status display	green LED per channel
Data for selecting a sensor	
Input voltage	
- Rated value	DC 24V
- for Signal "1"	15 28.8V
- for Signal "0"	0 5V
Input current	
- for Signal "1"	7mA
Input delay	
- from "0" to "1"	3ms
- from "1" to "0"	3ms
Connection of 2-wire-BEROs	possible
- Permitted bias current	1.5mA

321-1BL00 - DI 32xDC 24V

Order data DI 32xDC 24V VIPA 321-1BL00

Description The digital input module collects the binary control signals from the process level and transmits them isolated to the superordinated bus system. It has 32 channels and their status is monitored via LEDs.

Properties

- 32 inputs, isolated to the backplane bus
- Nominal input voltage DC 24V
- Useable for switches and approximate switches
- Status monitoring of the channels via LED

Structure





- [1] LEDs
- [2] flap with labeling strip
- [3] contact bar
- [4] flap opened with inner label

Pin assignment Circuit diagram Status monitor

Pin Assignment **Circuit diagram** LED Description 1 22 DI 32xDC24V not used .07 LEDs (green) 3 <u>23</u> 2...9 Input I+0.0...I+0.7 24 .0 I+0.0 to I+3.7 4 25 .1 .2 .3 .4 .5 .6 .7 5 12...19 Input I+1.0...I+1.7 from ca. 15V on. 26 6 27 7___ the signal is 20 Ground 8 28 recognized as "1" 9 29 21 not used and the according 22...29 Input I+2.0...I+2.7 ٢ LED is activated (= SM321 32...39 Input I+3.0...I+3.7 12 32 Γ 40 Ground 13 33 .0 П 14 34. .1 .1 .2 .3 .4 .5 .6 .7 15 35 <u>16</u> <u>36</u> 17 37 <u>18</u> <u>38</u> <u>19</u> 39 20 40 VIPA 321-1BL00 2M 1M

Schematic diagram Numeric representation





Numeric representation



Technical Data

Module name	VIPA 321-1BL00
Dimensions and weight	
Dimensions WxHxD	40x125x120mm
Weight	200g
Data for specific module	
Number of inputs	32
Programming specifications	
Input data	4byte
Voltages, Currents, Potentials	
Isolation	
 between channels and backplane bus 	yes
- between channels	yes
in groups of	16
Isolation tested with	DC 500V
Current consumption	
 from the backplane bus 	35mA
Power dissipation of the module	5.5W
Status, Interrupts, Diagnostic	
Status display	green LED per channel
Data for selecting a sensor	
Input voltage	
- Rated value	DC 24V
- for Signal "1"	15 28.8V
- for Signal "0"	0 5V
Input current	
- for Signal "1"	7mA
Input delay	
- from "0" to "1"	3ms
- from "1" to "0"	3ms
Connection of 2-wire-BEROs	possible
 Permitted bias current 	1.5mA

321-1FH00 - DI 16xAC120/230V

Order data

The digital input module collects the binary control signals from the process Description level and transmits them isolated to the superordinated bus system. It has 16 channels and their status is monitored via LEDs.

VIPA 321-1FH00

Properties

- 16 inputs, isolated in groups of 4 •
- Rated input voltage AC 120/230V
- Useable for switches

DI 16xAC 120/230V

Status monitoring of the channels via LED

Structure



- [1] LEDs
- flap with labeling strip [2]
- contact bar [3]
- flap opened with [4] inner label

Pin assignment Circuit diagram Status monitor

Pin Assignment

1 Neutral conductor 2 Input I+0.0 3 Input I+0.1 4 Input I+0.2 5 Input I+0.3 6 Input I+0.4 7 Input I+0.5 8 Input I+0.6 9 Input I+0.7 10 Neutral conductor 11 Neutral conductor 12 Input I+1.0 13 Input I+1.1 14 Input I+1.2 15 Input I+1.3 16 Input I+1.4 17 Input I+1.5 18 Input I+1.6 19 Input I+1.7





LED Description

.07 LEDs (green) I+0.0 to I+0.7 I+1.0 to I+1.7 from ca. AC 79V on, the signal is recognized as "1" and the according LED is activated

Neutral conductor

20

Schematic diagram



Technical Data

Module name	VIPA 321-1FH00	
Dimensions and weight		
Dimensions WxHxD	40x125x120mm	
Weight	200g	
Data for specific module		
Number of inputs	16	
Length of cable		
- unshielded	max. 600m	
- shielded	max. 1000m	
Programming specifications		
Input data	2bvte	
Voltages, Currents, Potentials	,	
Rated load voltage L1	120/230V	
All load voltages must be of the same phase.		
Number of inputs that can be triggered simultaneously		
- horizontal configuration up to 60°C	16	
- vertical configuration up to 40°C	16	
Isolation		
- between channels and backplane bus	ves	
- between the channels	ves	
in groups of	4	
Permitted potential difference		
- between M _{internal} and the inputs	AC 230V	
- between the inputs of the different groups	AC 500V	
Isolation tested with	DC 4000V	
Current consumption		
- from the backplane bus	35mA	
Power dissipation of the module	5W	
Status, Interrupts, Diagnostics		
Status display	green LED per channel	
Data for selecting a sensor		
Input voltage		
- Rated value	AC 120/230V	
- for signal "1"	79 to 264V	
- for signal "0"	0 to 40V	
- Frequency range	47 to 63Hz	
Input current		
- at signal "1"		
120V, 60Hz	typ. 5mA	
230V, 50Hz	typ. 7mA	
Input delay		
- "0" to "1"	max. 25ms	
- "1" to "0"	max. 25ms	
Input characteristic curve	According to IEC 61131, type 1	

Page

Chapter 4 Digital Output Modules

This chapter contains a description of the structure and the operation of the Outline VIPA digital output modules.

Content Topic Chapter 4 Digital Output Modules......4-1

System overview

Output modules SM 322

DC 24V output modules

are available at VIPA:



In the following you will get an overview over the digital output modules that

┢



Order data DC 24V output modules

Туре	Order No.	Page
DO 8xDC 24V 2A	VIPA 322-1BF01	4-4
DO 16xDC 24V 1A	VIPA 322-1BH01	4-6
DO 16xDC 24V 2A	VIPA 322-1BH41	4-8
DO 16xDC24V 0.5A for manual operation	VIPA 322-1BH60	4-10
DO 32xDC 24V 1A	VIPA 322-1BL00	4-13
AC 120/230V Output module



Order data	
AC 120/230V	
output modul	

Туре	Order No.	Page
DO 8xAC 120/230V 2A	VIPA 322-5FF00	4-16

Relay output module



Order data relay output module

Туре	Order No.	Page
DO 16xRelay	VIPA 322-1HH00	4-21

322-1BF01 - DO 8xDC 24V 2A

Order data DO 8xDC 24V 2A

VIPA 322-1BF01

Description The digital output module collects the binary control signals from the superordinated bus system and transmits them isolated to the process level. The module has to be provided with 24V via the front slot. It has 8 channels and their status is monitored via LEDs.

Properties

- 8 outputs, potential separated to the back panel bus
 - supply voltage DC 24V, output voltage 2A
 - useable for magnetic valve and DC contactor
 - LEDs for supply voltage and error messages
 - Status monitoring of the channels via LED

Structure





[1] LEDs

- [2] flap with labeling strip
- [3] contact bar
- [4] flap opened with inner label

Pin assignment Circuit diagram Status monitor

Pin	Assignment	Circuit diagram		LED	Description
1	Supply voltage DC 24V	1 1L+ 2 3	DO 8xDC24V	1L+, 2L+	LED (green) supply voltage is on
3	Output Q+0.0	<u>4</u>			
5	Output Q+0.1	$\frac{6}{7}$.1 –	.07	LEDs (green)
7	Output Q+0.2	8	.2		Q+0.0 to Q+0.7
9	Output Q+0.3	<u>9</u> 10	.3		As soon as an output is
10	Ground 1	1M	F ←		active, the according
11	Supply voltage DC 24V	1 <u>1 2L+</u> 1 <u>2</u>			LED is activated
13	Output Q+0.4			F	LED (red)
15	Output Q+0.5		.5		Error when overload or short circuits
17	Output Q+0.6		.6		
19	Output Q+0.7	19 19			
20	Ground 2	20	UIPA 322-1BF01 F ←		

Schematic diagram



Module name	VIPA 322-1BF01
Dimensions and weight	
Dimensions WxHxD	40x125x120mm
Weight	180g
Data for specific module	
Number of outputs	8
Length of cable	
- unshielded	600m
Programming specifications	
Output data	1byte
Voltages, Currents, Potentials	
Rated load voltage L+	DC 24V
Total current of the outputs (per group)	8A
Isolation	
 between channels and backplane bus 	yes
 between the channel groups 	yes
in groups of	4
Permitted potential difference	
- between the difference circuit	DC 75V / AC 60V
Insulation tested with	DC 500V
Current consumption	
- from the backplane bus	65mA
- from the load voltage L+ (without load)	68mA
Power dissipation of the module	7.5W
Status, Interrupts, Diagnostics	
Status display	green LED per channel
Group error display	red F-LED per group
Data for selecting an actuator	
Output voltage	
- at signal "1"	DC 24V
Output current	
- at signal "1"	
Rated value	2A
Output delay resistive load	(=0
- from "0" to "1"	150µs
	76µs
Lamp load max.	10W
Parallel connection of 2 outputs	possible
- for redundant triggering of a load	only outputs of same group
- for increase performance	only outputs of same group
Switch rate max.	4141-
- IOF resistive load	
- IOF INDUCTIVE IOAD (IEC 947-5-1, DC 13)	U.5HZ
- Iampi OBU	
Limit of the inductive circuit interruption voltage	typ. L+ (-52V)
Snort-circuit protection of the output	yes, electronic
- I nresnoia on	JA JA

322-1BH01 - DO 16xDC 24V 1A

Order data DO 16xDC 24V 1A

Description The digital output module collects the binary control signals from the superordinated bus system and transmits them isolated to the process level. The module has to be provided with 24V via the front slot. It has 16 channels and their status is monitored via LEDs.

VIPA 322-1BH01

Properties

- 16 outputs, potential separated to the back panel bus
 - supply voltage DC 24V, output voltage 1A
 - useable for magnetic valve and DC contactor
 - LEDs for supply voltage and error messages
 - Status monitoring of the channels via LED

Structure





- [1] LEDs
- [2] flap with labeling strip
- [3] contact bar
- [4] flap opened with inner label

Pin assignment Circuit diagram Status monitor

Pin	Assignment	Circuit diagram		LED	Description
1	Supply voltage	1 1L+ 2	DO 16xDC24V	1L+, 2L+	LED (green)
-	DC 24V				supply voltage is on
2	Output Q+0.0		.2		
			.4	.07	LEDs (green)
			.5		Q+0.0 to Q+1.7
9	Output Q+0.7	9	.7		As soon as an output is
10	Ground 1	1M	F ←		active the according
11	Supply voltage	11 21+			LED is activated
	DC 24V	12			
12	Output $O+1 0$			F	LED (red)
12	Output Q+1.0				
	•		.5		Error when overload or
10					short circuits
19		19	<u>X 2</u> 3 4 F ←		
20	Ground 2	20 2M	VIPA 322-1BH01		

Schematic diagram



Module name	VIPA 322-1BH01
Dimensions and weight	
Dimensions WxHxD	40x125x120mm
Weight	200g
Data for specific module	
Number of outputs	16
Programming specifications	
Output data	2byte
Voltages, Currents, Potentials	
Rated load voltage L+	DC 24V
Isolation	
 between channels and backplane bus 	yes
 between the channels 	yes
in groups of	8
Isolation tested with	DC 500V
Current consumption	
 from the backplane bus 	110mA
 from the load voltage L+ (without load) 	30mA
Power dissipation of the module	4W
Status, Interrupts, Diagnostics	
Status display	green LED per channel
Group error display	red F-LED per group
Data for selecting an actuator	
Output current	
- at signal "1"	
Rated value	1A
Switch rate max.	
- for resistive load	1kHz
- for inductive load (IEC 947-5-1, DC 13)	0.5Hz
- lamp load	1Hz
Limit of the inductive circuit interruption voltage	typ. L+ (-52V)

322-1BH41 - DO 16xDC 24V 2A

Order data DO 16xDC 24V 2A VIPA 322-1BH41

Description The digital output module collects the binary control signals from the superordinated bus system and transmits them isolated to the process level. The module has to be provided with 24V via the front slot. It has 16 channels and their status is monitored via LEDs.

Properties

- 16 outputs, potential separated to the back panel bus
 - supply voltage DC 24V, output voltage 2A
 - useable for magnetic valve and DC contactor
 - LEDs for supply voltage and error messages
 - Status monitoring of the channels via LED

Structure





- [1] LEDs
- [2] flap with labeling strip
- [3] contact bar
- [4] flap opened with inner label

Pin assignment Circuit diagram Status monitor

Pin	Assignment	Circuit diagram		LED	Description
1	Supply voltage	<u>1 1L+</u> 2	DO 16xDC24V	1L+, 2L+	LED (green)
2			.0		supply voltage is on
Ζ	Output Q+0.0		.2	0 7	
•			.4	.07	LEDS (green)
		8_0	.6		Q+0.0 to Q+1.7
9	Output Q+0.7	<u>9</u> 10	.7		As soon as an output is
10	Ground 1	1M			active the according
11	Supply voltage	11 2L+			LED is turned on
	DC 24V	12	.0		
12	Output Q+1.0		.1	F	LED (red)
. –	ouput d' no		.3		
•		16 17 $-$.5		Error when overload or
			.6		short circuits
19	Output Q+1.7		$ \begin{array}{c c} & & & \\ \hline \\ \hline$		
20	Ground 2	20 2M	VIPA 322-1BH41		

Schematic diagram



Module name	VIPA 322-1BH41
Dimensions and weight	
Dimensions WxHxD mm	40x125x120mm
Weight	200g
Data for specific module	
Number of outputs	16
Programming specifications	Project engineering as 322-1BH01
Output data	2byte
Voltages, Currents, Potentials	
Rated load voltage L+	DC 24V
Total current of the output (per group)	8A
Isolation	
 between channels and backplane bus 	yes
- between the channels	yes
in groups of	8
Isolation tested with	DC 500V
Current consumption	
 from the backplane bus 	110mA
 from the load voltage L+ (without load) 	30mA
Power dissipation of the module	4W
Status, Interrupts, Diagnostics	
Status display	green LED per channel
Group error display	red F-LED per group
Data for selecting an actuator	
Output current	
- at signal "1"	
Rated value	2A
Switch rate max.	
- for resistive load	1kHz
- for inductive load (IEC 947-5-1, DC 13)	0.5Hz
- lamp load	1Hz
Limit of the inductive circuit interruption voltage	typ. L+ (-52V)

322-1BH60 - DO 16xDC 24V 0.5A for manual operation

Order data DO 16xDC 24V 0.5A HB VIPA 322-1BH60

Description The module is configured as in-/output module. It has 16 channels and their status is monitored via LEDs. Besides of the LEDs the frontside provides a row of switches for manual res. Automatic operation, i.e. every output has a 3 setting switch with the positions automatic, manual 0 and manual 1.

Properties

- 16 outputs, potential separated to the back panel bus
 - 1 input, potential separated, for activation of all outputs
 - 3 setting switch per channel (automatic, manual 0 and manual 1)
 - 16 inputs, switch status via input word
 - supply voltage DC 24V, output voltage 0.5A
 - LEDs for supply voltage and error messages
 - Status monitoring of the channels via LED

Structure





- [1] LEDs
- [2] flap with labeling strip
- [3] switch bar
- [4] contact bar
- [5] flap opened with inner label

Pin assignment Circuit diagram Status monitor

Pin Assignment

Circuit diagram





- LED Description
- L+ LED (green) supply voltage is on
- .07 LEDs (green) Q+0.0 to Q+1.7 As soon as an output is active, the according LED is turned on
 - F LED (red) Error when overload or short circuits



Deployment Please regard that the module is installed as 323-1BL00. You are allowed to request the switch position of the according channel via the input word. For this is valid:

triple switch	input word	Description
10A	I.x=0	Manual 1: output channel always activated
1 0 A	I.x=0	Manual 0: output channel always de-activated
1 0 A	l.x=1	Automatic: control via PLC application

The control of the outputs happens via output word.



Note!

By connecting DC 24V at the input (Pin 10), all outputs are set to "1". This input cannot be evaluated by the PLC user program.

Module name	VIPA 322-1BH60
Dimensions and weight	
Dimensions WxHxD	40x125x120mm
Weight	200g
Data for specific module	Ť
Number of outputs	16
Number of inputs	1 (switch input for A.x="1")
Length of cable	
- unshielded	600m
Programming specification	Project engineering as 323-1BL00
Input data	2byte (switch input)
Output data	2byte
Voltages Currents Potentials	
Rated load voltage I +	DC 24V
Sum current per group	84
Isolation	0,1
- between channels und backplane bus	Ves
Isolation tested with	DC 500V
Current consumption	
- from the backplane bus	100mA
- from the load voltage I + (without load)	140mA
Power dissipation of the module	6W
Status Interrupts Diagnostics	
Status display	green LED per channel
Group error display	red F-LED
Data for selecting an actuator	
Output voltage	
- at signal "1"	DC 24V
Output current	
- at signal "1"	
Rated value	0.5A
Output delay resistive load	
- from "0" to "1"	100us
- from "1" to "0"	350µs
Lamp load max.	10Ŵ
Parallel connections of 2 outputs	possible
- for redundant triggering of a load	only outputs of the same group
- to increase performance	no
Actuation of digital input	possible
Switch rate max.	
- for resistive load	1kHz
- for inductive load (IEC 947-5-1, DC 13)	0.5Hz
- lamp load	1Hz
Limit of the inductive circuit interruption voltage	typ. L+ (-52V)
Short-circuit protection of the output	ves, electronic
- Threshold on	1A

322-1BL00 - DO 32xDC 24V 1A

Order data	DO 32xDC 24V 1A VIPA 322-1BL00
Description	The digital output module collects the binary control signals from the superordinated bus system and transmits them isolated to the process level. The module has to be provided with 24V via the front slot. It has 16 channels and their status is monitored via LEDs.
Properties	 32 outputs, potential separated to the back panel bus Supply voltage DC 24V Output voltage 1A per channel Useable for magnetic valve and DC contactor LEDs for supply voltage and error messages Activity LED per channel
Structure	[1] LEDs

3 -

2

[2] flap with labeling strip

[3] contact bar

[4] flap opened with inner label

Pin assignment Status monitor

Pin	Assignment		LED	Description
1	Supply voltage 1L+		1/3L+, 2/4L+	LED (green)
2	Output Q+0.0			supply voltage is on
9	 Output Q+0.7		.07	LEDs (green)
10	Ground 1			Q+0.0 to Q+3.7
11	Supply voltage 2L+	□ .7 □ □ 1/3 F □ ←		As soon as an output is
12	Output Q+1.0	SM322		active, the according LED
				is turned on
19	Output Q+1.7			
20	Ground 2		1/3F, 2/4F	LED (red)
21	Supply voltage 3L+	.6		Error when overload or short circuits
22	Output Q+2.0	7 7 7 72 _		Short circuits
29	Output Q+2.7			
30	Ground 3			
31	Supply voltage 4L+			

...

Output Q+3.0

Output Q+3.7

Ground 4

Circuit diagram Schematic diagram

32

...

39

40





Schematic diagram



Numeric representation

From the application level to the hardware level the data is stored in Motorola-Format, i.e. "ready for reading".

The following picture shows the output of the number 287454020dez res. 11223344hex on the outputs of the 32pin output modules



Module name	VIPA 322-1BL00	
Dimensions and weight		
Dimensions WxHxD	40x125x120mm	
Weight	200g	
Data for specific module		
Number of outputs	32	
Programming specifications		
Output data	4byte	
Voltages, Currents, Potentials		
Rated load voltage L+	DC 24V	
Isolation		
 between channels and backplane bus 	yes	
 between the channels 	yes	
in groups of	8	
Isolation tested with	DC 500V	
Current consumption		
 from the backplane bus 	200mA	
 from load voltage L+ (without load) 	30mA	
Power dissipation of the module	5W	
Status, Interrupts, Diagnostics		
Status display	green LED per channel	
Group error display	red F-LED per group	
Data for selecting an actuator		
Output current		
- at signal "1"		
Rated value	1A	
Switch rate max.		
- for resistive load	1kHz	
- for inductive load (IEC 947-5-1, DC 13)	0.5Hz	
- lamp load	1Hz	
Limit of the inductive circuit interruption voltage	typ. L+ (-52V)	

322-5FF00 - DO 8xAC 120/230V 2A

Order data	DO 8xAC 120/230V 2A VIPA 322-5FF00
Description	The digital output module collects the binary control signals from the superordinated bus system and transmits them isolated to the process level. It has 8 channels and their status is monitored via LEDs.
Properties	 8 outputs, isolated between the channels and to the back plane bus Rated load voltage AC 120/230V Output current per channel 2A Suitable for AC solenoid valves, contactors, motor starters, fractional h.p. motors and indicator lights Group error display Channel-specific status LEDs Programmable substitute value output
Structure	[1] LEDs

Structure





- flap with labeling strip [2]
- [3] contact bar
- flap opened with [4] inner label

Pin assignment Status monitor

Pin Assignment

- 1 Rated load voltage 1L
- 4 Q+0.0
- 7 Rated load voltage 2L
- 10 Q+0.1
- 11 Rated load voltage 3L
- 14 Q+0.2
- 17 Rated load voltage 4L
- 20 Q+0.3
- 21 Rated load voltage 5L
- 24 Q+0.4
- 27 Rated load voltage 6L
- 30 Q+0.5
- 31 Rated load voltage 7L
- 34 Q+0.6
- 37 Rated load voltage 8L
- 40 Q+0.7



LED Description

- SF LED (red) Group errror LED, error if module is not supplied with parameters by the CPU
- .07 LED (green) Q+0.0 to Q+0.7 As soon as an output is active, the according LED is turned on

Circuit diagram Schematic diagram



Circuit diagram

Schematic diagram





14



Caution!

The outputs must be protected by a fast-acting 3.15A, AC 250V fuse. When mounted in a hazardous area, the fuse may only be removed by a tool.

Parameterization

Overview	 There are the following possibilities for parameterization: Parameterization by WinPLC7 from VIPA or by hardware configuration of Siemens SIMATIC manager. Parameterization during run time by means of SFCs
Parameterization by hardware configuration	 To be compatible to the Siemens SIMATIC manager the following steps are to be accomplished: Start the hardware configurator from Siemens. Create a new project. Configure your CPU. Link-up your System 300V modules in the plugged-in sequence starting with slot 4. Here the digital output modules of VIPA are to be projected as digital output modules of Siemens in accordance with the following rules: VIPA 322-5FF00 to be configured as 6ES7 322-5FF00-0AB0 The digital output modules can be found at the hardware catalog at <i>Simatic 300 > SM-300</i>. If needed parameterize the CPU respectively the modules. The parameter window appears as soon as you double click on the according module. At this window the according parameter can be changed. Save your project, switch the CPU to STOP and transfer your project to the CPU. As soon as the CPU is switched to RUN the parameters are transferred to the connected modules.
Parameters	 The following parameters can be adjusted at the digital output modules: Reaction at CPU-STOP Switch substitute value "1" More description of the parameters may be found at the following pages.

Parameterization during run time by means of SFCs

If the module gets parameters, which are not supported by the module, for example a current module is to be configured as a voltage module, these parameters are interpreted as wrong parameters and an error is initialized. At the parameterization, a 4byte long parameter area is set in the record set 1. Deploying the SFCs 56, 57 and the SFB 53, you may alter parameters during run time and transfer them to the module.

Parameter Record set 1

	Record set 1 (Byte 0 to 3):	Default value
Byte	Bit 7 Bit 0	
0	Reaction to CPU Stop	00h
	Bit 0: Keep last valid value	
	Bit 1: Substitute a value	
	Bit 6: reserved	
	Bit 7: reserved	
1	Substitute value	00h
	Bit 0: Substitute value "1" on channel 0	
	Bit 1: Substitute value "1" on channel 1	
	Bit 2: Substitute value "1" on channel 2	
	Bit 3: Substitute value "1" on channel 3	
	Bit 4: Substitute value "1" on channel 4	
	Bit 5: Substitute value "1" on channel 5	
	Bit 5: Substitute value "1" on channel 6	
	Bit 7: Substitute value "1" on channel 7	
2	not relevant	00h
3	not relevant	00h



Note!

You should only enable the parameters in byte 0, "Hold last valid value" and "Enable substitute value" as an alternative.

Reaction to CPU-Stop

Here the module reaction at CPU-STOP may be set. There are the following possibilities:

- Keep last valid value The value of each channel is freezed when the CPU is stopped
- Substitute a value At CPU-STOP each channel is substituded by a value which may be assigned by byte 1.

Module name	VIPA 322-5FF00
Dimensions and weight	
Dimensions WxHxD	40x125x120mm
Weight	200g
Data for specific module	
Number of outputs	8
Length of cable	
- unshielded	600m
- shielded	1000m
Programming specifications	
Output data	1byte
Voltages, Currents, Potentials	
Rated load voltage L1	AC 120/230V
Total current of the outputs (Module)	8A
- horizontal configuration	
up to 40°C	max. 8A
up to 60°C	max. 4A
- vertical configuration	
up to 40°C	max. 4A
Isolation	
- between channels and backplane bus	ves
- between the channel groups	ves
in groups of	1
Permitted potential difference	
- between Minternal and the outputs	AC 230V
- between outputs	AC 500V
Isolation tested with	
- between Minternal and the outputs	AC 1500V
- between the outputs of the different groups	AC 2000V
Current consumption	
- from the backplane bus	max. 100mA
- from the load voltage L1 (without load)	max. 2mA
Power dissipation of the module	typ 8.6W
Status, Interrupts, Diagnostics	
Status display	green LED per Channel
Diagnostic functions	J
- Group error display	red SF-LED
Data for selecting an actuator	
Output voltage	
- at signal "1"	
at maximal current	L1 (-1.5V)
at minimal current	L1 (-8.5V)
Output current	
- at signal "1"	
Rated value	2A
permitted range for 0°C to 40°C	10mA bis 2A
permitted range for 40°C to 60°C	10mA bis 1A
permitted surge current (per group)	max. 20A (with 2 half-waves)
- at signal "0" (leakage current)	max. 2mA
Zero cross inhibit voltage	max. 60V
Size of the motor starter	max. size 5 to NEMA
Lamp load	max. 50W
Connecting two outputs in parallel	
- for redundant triggering of a load	possible
- to increase performance	not possible
Triggering a digital input	possible
Switch rate	
- for resistive load	max. 10Hz
- inductive loads, according (IEC 947-5-1. AC 13)	max. 0.5Hz
- bei Lampenlast	max. 1Hz
Short-circuit protection of output	3.15A/250V fuse, fast-acting

322-1HH00 - DO 16xRelay

Order data DO 16xRelais VIPA 322-1HH00

Description The relay output module collects the binary control signals from the superordinated bus system and transmits them via relay outputs to the process level. The module electronics are provided via the back panel bus. It has 16 channels working as switches, and their status is monitored via LEDs.

Properties

- 16 Relay outputs in groups á 8
- Power supply via back panel bus
- Load capacity voltage AC 230V / DC 30V
- Maximal contact rating per channel 5A
- useable for small motors, lamps, magnetic valve and DC contacter
- Activity LED per channel

Structure





- [1] LEDs
- [2] flap with labeling strip
- [3] contact bar
- [4] flap opened with inner label

Pin assignment Status monitor

- Pin Assignment
- 1 1L1
- 2 Relay-Output Q+0.0
-
- 9 Relay-Output Q+0.7
- 10 L+DC24V
- 11 2L1
- 12 Relay-Output Q+1.0
-
- 19 Relay-Output Q+1.7
- 20 Ground



LED Description

.0.....7 LED (green) Q+0.0 to Q+1.7 As soon as an output is active, the according LED is turned on diagram



Module name	VIPA 322-1HH00		
Dimensions and weight			
Dimensions WxHxD	40x125x120mm		
Weight	200g		
Data for specific module			
Number of outputs	16 via relay		
Programming specification			
Output data	2byte		
Voltages, Currents, Potentials			
Rated supply voltage of the electronics L+	5V		
Total current of the outputs (per group)	8A		
Isolation			
 between channels and backplane bus 	yes		
 between the channels 	yes		
in groups of	8		
Isolation tested with	DC 500V		
Current consumption			
 from the backplane bus 	80mA		
- from power supply L+	150mA		
Power dissipation of the module	4W		
Status, Interrupts, Diagnostics			
Status display	green LED per channel		
Data for selecting an Actuator			
Minimum load voltage / current	AC 230V or DC 30V		
Output current			
- Nominal value	4A		
- permissible	5A		
- Lamp load	500mA		
- inductive load	250mA		
- capacitive load	250mA		
- Sum current per group	AC 230V: 5A DC 30V: 5A		

Chapter 5 Digital Input/Output Modules

Outline This chapter contains a description of the structure and the operation of the VIPA digital in-/output modules.

Content Topic Page Chapter 5 Digital Input/Output Modules 5-1 System overview 5-2 Security hints for DIO modules 5-2 323-1BH00 - DIO 16xDC 24V 1A 5-3 323-1BH01 - DI 8xDC 24V, DO 8xDC 24V 1A 5-5 323-1BL00 - DI 16xDC 24V, DO 16xDC 24V 1A 5-7

System overview

I/O modules SM 323 In the following you will get an overview over the digital input/output modules that are available at VIPA:



Order data	Туре	Order No.	Page
I/O modules	DIO 16xDC 24V 1A	VIPA 323-1BH00	5-3
	DI 8xDC 24V, DO 8xDC 24V 1A	VIPA 323-1BH01	5-5
	DI 16xDC 24V, DO 16xDC 24V 1A	VIPA 323-1BL00	5-7

Security hints for DIO modules



Attention!

Please regard that the voltage applied to an output channel must be \leq the voltage supply applied to L+.

Due to the parallel connection of in- and output channel per group, a set output channel may be supplied via an applied input signal.

Thus, a set output remains active even at power-off of the voltage supply with the applied input signal.

Non-observance may cause module demolition.

323-1BH00 - DIO 16xDC 24V 1A

DIO 16xDC 24V 1A VIPA 323-1BH00 **Order Data**

Description The module is a combined module. It has 16 channels that can be used either as inputs or outputs. Every channel supports a diagnostic function, i.e. as soon as an output is active, the according input is set. If there is a short circuit at the load, the according input is reset and the error may be recognized by analyzing the input.

Properties 16 channels, isolated to the backplane bus (as input or output) •

- **Diagnostic function** •
- Nominal input voltage DC 24V / supply voltage DC 24V
- Output current 1A
- LED for error message at overload, overheat or short circuit •
- Activity monitoring of the channels via LED •

Structure





- [1] LEDs
- [2] flap with labeling strip
- contact bar [3]
- flap opened with [4] inner label

Pin assignment Circuit diagram Status monitor

Pin	Assignment
-----	------------

Circuit diagram

G.

-6-

3 -6-4 -6-

5

6

7 -6-

8

9 -6-

10

11

16

17

18 -6-19

20 -

-G-

6

- Supply voltage 1 +DC 24V
- 2 In-/Output I/Q+0.0
-
- 9 In-/Output I/Q+0.7
- 10 Ground
- 11 Supply voltage +DC 24V
- 12 In-/Output I/Q+1.0
-
- In-/Output I/Q+1.7 19
- Ground 20



LED Description

- LED (green) 1L+, 2L+ supply voltage is on
- .07 LED (green) per Byte As soon as an input signal "1" or an active output is recognized. the according LED is activated

LED (red) error at overload or short circuit

F



Mobule Haine VTP 322-1500 Dimensions and Weight 40x125x120mm Weight 210g Data for specific module 16 Number of Inputs 16 Number of Outputs 16 Programming specifications Project Engineering as 323-1BL00 Input data 2Byte Output data 2Byte Voltages, Currents, Potentials 2 Rated load voltage L+ DC 24V Isolation tested with DC 500V Current consumption 130mA - from the backplane bus 130mA - from the backplane bus 130mA - from load voltage L+ (without load) 30mA Power dissipation of the module 4W Status display green LED per channel Group error display red F-LED Data for selecting a sensor 11 Input voltage 05V - for signal "0" 05V Input durent 7mA - form "1" to "0" 3ms - form "1" to "0" 3ms - form signal "1" 7mA Input delay - form "1" to "0" - form signal "1" 7mA Input delay - form "1" to "0" - for signal "1" DC 24	Madula noma	
Dimensions WitkD 40x125x120mm Weight 210g Data for specific module 16 Number of Inputs 16 Programming specifications Project Engineering as 323-1BL00 Input data 2Byte Output data 2Byte Voltages, Currents, Potentials 2Byte Rated load voltage L+ DC 24V Isolation yes - between channels and backplane bus yes Isolation tested with DC 500V Current consumption 130mA - from load voltage L+ (without load) 30mA Power dissipation of the module 4W Status, Interrupts, Diagnostics 1 Status, Interrupts, Diagnostics 1 Input voltage DC 24V - for signal "1" 15 28.8V - for signal "0" 0 5V Input delay 7mA Input voltage - at signal "1" - for signal "1" 7mA Input delay 3ms - for signal "1" 7mA Input voltage - at signal "1" - for signal "1" 7mA Input delay - for signal "1" - for signal "1" 7mA Input delay - for signal "1" <	Nodule name	VIPA 323-1BH00
Differentiations 40x12sx120mm Weight 210g Data for specific module 16 Number of Inputs 16 Number of Outputs 16 Programming specifications Project Engineering as 323-1BL00 Input data 2Byte Output data 2Byte Voltages, Currents, Potentials 2Byte Rated load voltage L+ DC 24V Isolation yes - between channels and backplane bus yes - between channels and backplane bus yes - from the backplane bus yes - from the backplane bus 130mA - from the backplane bus 130mA - from load voltage L+ (without load) 30mA Power dissipation of the module 4W Status display green LED per channel Group error display red F-LED Data for selecting a sensor Input voltage - for signal "1" 7mA Input delay - from "0" to "1" - for signal "1" 7mA Input delay - from "1" or 0" - at signal "1" 0c. 44V - or signal "1" 7mA Input delay - from "1" or 0" - from "1" to "0" 3ms <t< td=""><td>Dimensions and Weight</td><td>10:125:120mm</td></t<>	Dimensions and Weight	10:125:120mm
Weight 210g Data for specific module 16 Number of Inputs 16 Number of Outputs 16 Programming specifications Project Engineering as 323-1BL00 Input data 2Byte Output data 2Byte Voltages, Currents, Potentials 1 Rated load voltage L+ DC 24V Isolation yes - between channels and backplane bus yes Isolation tested with DC 500V Current consumption 130mA - from the backplane bus 130mA - from load voltage L+ 4W Status, Interrupts, Diagnostics 1 Status display green LED per channel Group error display red F-LED Data for selecting a sensor 1 Input voltage DC 24V - for signal "1" 15 28.8V - for signal "1" 7mA Input delay 3ms - for signal "1" 7mA Input delay 3ms - for signal "1" 7mA - for signal "1" 1A (max. 1.2A) - at signal "1"		40x125x120mm
Data for specific module 16 Number of Inputs 16 Number of Outputs 16 Programming specifications Project Engineering as 323-1BL00 Input data 2Byte Output data 2Byte Voltages, Currents, Potentials 2 Rated load voltage L+ DC 24V Isolation yes - between channels and backplane bus yes Isolation tested with DC 500V Current consumption 130mA - from the backplane bus 130mA - from load voltage L+ (without load) 30mA Power dissipation of the module 4W Status, Interrupts, Diagnostics 16 Status display green LED per channel Group error display red F-LED Data for selecting a sensor 11 Input voltage 0 5V Input voltage 0 5V Input voltage 0 5V Input voltage 0 5V Input outrent 3ms - for signal "1" 7mA Input outrent 3ms - for signal "1"<		210g
Number of inputs 16 Programming specifications Project Engineering as 323-1BL00 Input data 2Byte Output data 2Byte Voltages, Currents, Potentials	Data for specific module	10
Number of Outputs 16 Programming specifications Project Engineering as 323-1BL00 Input data 2Byte Output data 2Byte Voltages, Currents, Potentials 2Byte Rated load voltage L+ DC 24V Isolation yes - between channels and backplane bus yes Isolation tested with DC 500V Current consumption 130mA - from the backplane bus 130mA - from the dackplane bus 30mA Power dissipation of the module 4W Status, Interrupts, Diagnostics 30mA Status display green LED per channel Group error display red F-LED Data for selecting a sensor 15 28.8V - for signal "1" 0 5V Input delay -form "0" to "1" - for signal "1" 7mA Input delay -form "0" to "1" - for signal "1" 0C 24V Output voltage - - at signal "1" DC 24V Output voltage - - at signal "1" DC 24V Output voltage - - at signal "1" DC 24V Output voltage - - at signal "1" DC 24V	Number of Inputs	16
Programming specifications Project Engineering as 323-1BL00 Input data 2Byte Output data 2Byte Voltages, Currents, Potentials DC 24V Isolation yes - between channels and backplane bus yes Isolation tested with DC 500V Current consumption 130mA - from the backplane bus 130mA - from the backplane bus 130mA Status, Interrupts, Diagnostics 9 Status, display green LED per channel Group error display red F-LED Data for selecting a sensor Input voltage - for signal "1" 15 28.8V - for signal "0" 0 5V Input current 7mA - for signal "1" 7mA Input delay 3ms - for signal "1" 2ms Output current 0 - for signal "1" 7mA Input delay 2ms - for signal "1" 7mA Input delay 0 - at signal "1" DC 24V Output current 0	Number of Outputs	16
Input data 2Byte Output data 2Byte Output data 2Byte Voltages, Currents, Potentials 2Byte Rated load voltage L+ DC 24V Isolation yes - between channels and backplane bus yes Isolation tested with DC 500V Current consumption 130mA - from the backplane bus 130mA - from the backplane bus 30mA Power dissipation of the module 4W Status, Interrupts, Diagnostics 3 Status display green LED per channel Group error display red F-LED Data for selecting a sensor Input voltage - for signal "1" 15 28.8V - for signal "0" 0 5V Input current - for signal "1" - for signal "0" 0 5V Input delay - for signal "1" - for signal "1" 7mA Input delay - for signal "1" - for signal "1" 2ms - for signal "1" 0 - a	Programming specifications	Project Engineering as 323-1BL00
Output data 2Byte Voltages, Currents, Potentials DC 24V Isolation DC 24V Isolation yes Isolation tested with DC 500V Current consumption 130mA - from the backplane bus 130mA - from the backplane bus 130mA - from load voltage L+ (without load) 30mA Power dissipation of the module 4W Status display green LED per channel Group error display red F-LED Data for selecting a sensor 1528.8V Input voltage 05V Input current 1528.8V - for signal "0" 05V Input delay 3ms - for signal "1" 7mA Input delay 3ms - for signal "1" 7mA Input voltage 05V Input current 05V Input delay 14.(max. 1.2A) - at signal "1" DC 24V Output current 5ms - for signal "1" 7mA Input delay 14.(max. 1.2A)	Input data	2Byte
Voltages, Currents, Potentials Rated load voltage L+ DC 24V Isolation yes - between channels and backplane bus yes Isolation tested with DC 500V Current consumption - - from the backplane bus 130mA - from load voltage L+ (without load) 30mA Power dissipation of the module 4W Status, Interrupts, Diagnostics Status display Group error display green LED per channel Group error display red F-LED Data for selecting a sensor Input voltage - for signal "1" 15 28.8V - for signal "0" 0 5V Input current - - for signal "0" 0 5V Input delay - for signal "1" - for signal "1" 7mA Input delay - - at signal "1" DC 24V Output current - - at signal "1" DC 24V Output current - - at signal "1" DC 24V Output curren	Output data	2Byte
Rated load voltage L+ DC 24V Isolation yes - between channels and backplane bus yes Isolation tested with DC 500V Current consumption 130mA - from the backplane bus 130mA - from the backplane bus 130mA - from load voltage L+ (without load) 30mA Power dissipation of the module 4W Status, Interrupts, Diagnostics 5 Status display green LED per channel Group error display red F-LED Data for selecting a sensor 1 Input voltage 0 5V Input current 0 5V Input delay 7mA Input delay 3ms - for signal "1" 7mA Input delay 3ms - for signal "1" 3ms - for signal "1" 3ms - for signal "1" 0 5V Input delay - - for signal "1" 7mA Input delay - - at signal "1" 0 C 24V Output voltage - - at signal "1" DC 24V Output current - - at signal "1" DC 24V Output current -	Voltages, Currents, Potentials	
Isolation - between channels and backplane bus yes Isolation tested with DC 500V Current consumption 130mA - from the backplane bus 130mA - from load voltage L+ (without load) 30mA Power dissipation of the module 4W Status, Interrupts, Diagnostics	Rated load voltage L+	DC 24V
- between channels and backplane bus yes Isolation tested with DC 500V Current consumption - - from the backplane bus 130mA - from load voltage L+ (without load) 30mA Power dissipation of the module 4W Status, Interrupts, Diagnostics - Status display green LED per channel Group error display red F-LED Data for selecting a sensor - Input voltage - - Rated value DC 24V - for signal "1" 15 28.8V - for signal "0" 0 5V Input current - - for signal "1" 7mA Input delay - - from "0" to "1" 3ms - from "0" to "1" 3ms - from "0" to "1" 3ms - at signal "1" DC 24V Output voltage - - at signal "1" DC 24V Output current - - at signal "1" DC 24V Output current - - at signal "1" DC 24V Output current - - at signal "1" DC 24V Output current - - at signal "1" DC 24V	Isolation	
Isolation tested with DC 500V Current consumption 130mA - from the backplane bus 130mA - from load voltage L+ (without load) 30mA Power dissipation of the module 4W Status, Interrupts, Diagnostics green LED per channel Group error display green LED per channel Data for selecting a sensor Input voltage - Rated value DC 24V - for signal "1" 15 28.8V - for signal "0" 0 5V Input current 7mA Input delay 3ms - for signal "1" 3ms - for signal "1" 3ms - from "0" to "1" 3ms - from "1" to "0" 3ms Data for selecting an actuator 0utput current - at signal "1" DC 24V Output current 7mA Input delay 7mA - from "0" to "1" 3ms - from "1" to "0" 3ms Data for selecting an actuator 0utput current - at signal "1" DC 24V Output current - - at signal "1" C24V Output current - - at signal "1" C24V Output current - <t< td=""><td> between channels and backplane bus </td><td>yes</td></t<>	 between channels and backplane bus 	yes
Current consumption 130mA - from the backplane bus 130mA - from load voltage L+ (without load) 30mA Power dissipation of the module 4W Status, Interrupts, Diagnostics green LED per channel Group error display green LED per channel Group error display red F-LED Data for selecting a sensor Input voltage - Rated value DC 24V - for signal "1" 15 28.8V - for signal "0" 0 5V Input current - for signal "1" - for signal "1" 7mA Input delay - from "0" to "1" - from "0" to "1" 3ms - from "1" to "0" 3ms Data for selecting an actuator Output voltage - at signal "1" DC 24V Output voltage - at signal "1" - at signal "1" DC 24V Output current - at signal "1" - at signal "1" DC 24V Output current - at signal "1" - at signal "1" DC 24V Output current - at signal "1" - at signal "1"	Isolation tested with	DC 500V
- from the backplane bus 130mA - from load voltage L+ (without load) 30mA Power dissipation of the module 4W Status, Interrupts, Diagnostics 30mA Status display green LED per channel Group error display red F-LED Data for selecting a sensor 15 Input voltage DC 24V - for signal "1" 15 - for signal "0" 0 Input current 7mA - from "0" to "1" 3ms - from "0" to "1" 3ms Data for selecting an actuator 0 Output voltage - at signal "1" - for signal "1" DC 24V - for signal "1" 7mA Input delay - for signal - for signal "1" 7mA Output voltage - at signal - at signal "1" DC 24V Output current - at signal "1" - at signal "1" DC 24V Output current - at signal "1" - at signal "1" DC 24V Output current - at signal "1" - for signal "1" <td< td=""><td>Current consumption</td><td></td></td<>	Current consumption	
- from load voltage L+ (without load) 30mA Power dissipation of the module 4W Status, Interrupts, Diagnostics 9 Status display green LED per channel Group error display red F-LED Data for selecting a sensor 1 Input voltage DC 24V - Rated value DC 24V - for signal "1" 15 28.8V - for signal "0" 0 5V Input current 7mA - for signal "1" 7mA Input delay 3ms - for signal "1" 7mA Output voltage - at signal "1" - at signal "1" DC 24V Output voltage - at signal "1" - at signal "1" DC 24V Output current - at signal "1" - at signal "1" DC 24V Output current - at signal "1" - at signal "1" DC 24V Output current - at signal "1" - at signal "1" DC 24V Output current - at signal "1" - at signal "1" DC 24V Output current - at	- from the backplane bus	130mA
Power dissipation of the module 4W Status, Interrupts, Diagnostics green LED per channel Group error display red F-LED Data for selecting a sensor input voltage - Rated value DC 24V - for signal "1" 15 28.8V - for signal "0" 0 5V Input current 7mA Input delay 3ms - from "0" to "1" 3ms - from "0" to "1" 3ms - from "1" to "0" 3ms Data for selecting an actuator 0 Output voltage - at signal "1" - at signal "1" DC 24V Status display 3ms Data for selecting an actuator 0 Output voltage - at signal "1" - at signal "1" DC 24V Output current - at signal "1" - at signal "1" DC 24V Output current - at signal "1" - for resistive load 1A (max. 1.2A) Lamp load max. 5W per group Switch rate max. - for resistive load - for resistive load 1kHz <	- from load voltage L+ (without load)	30mA
Status, Interrupts, Diagnostics green LED per channel Group error display red F-LED Data for selecting a sensor nput voltage Input voltage DC 24V - Rated value DC 24V - for signal "1" 15 28.8V - for signal "0" 0 5V Input current 7mA - for signal "1" 7mA Input delay 3ms - from "0" to "1" 3ms - for signal "1" DC 24V Output delay 0 - for signal "1" 7mA Input delay 3ms - from "0" to "1" 3ms - for signal "1" DC 24V Output voltage 2000000000000000000000000000000000000	Power dissipation of the module	4W
Status display green LED per channel Group error display red F-LED Data for selecting a sensor Input voltage - Rated value DC 24V - for signal "1" 15 28.8V - for signal "0" 0 5V Input current 7mA Input delay 3ms - for signal "1" 7mA Input delay 3ms - for signal "1" 7mA Output voltage 0 5V Input delay - from "0" to "1" - for signal "1" 7mA Output voltage - from "1" to "0" - at signal "1" DC 24V Output voltage - at signal "1" - at signal "1" DC 24V Output current - at signal "1" - at signal "1" DC 24V Output current - at signal "1" - at signal "1" DC 24V Output current - at signal "1" - at signal "1" DC 24V Output current - at signal "1" - at signal "1" DC 24V Output current - at signal "1"	Status, Interrupts, Diagnostics	
Group error display red F-LED Data for selecting a sensor Input voltage Input voltage DC 24V - for signal "1" 15 28.8V - for signal "0" 0 5V Input current 7mA Input delay 3ms - for m "0" to "1" 3ms - for signal "1" 7mA Input delay 3ms - for m "0" to "1" 3ms - for selecting an actuator 0utput voltage - at signal "1" DC 24V Output voltage 14 (max. 1.2A) Lamp load max. 5W per group Switch rate max. 5W per group - for resistive load 1kHz	Status display	green LED per channel
Data for selecting a sensor Input voltage - Rated value DC 24V - for signal "1" 15 28.8V - for signal "0" 0 5V Input current 7mA Input delay 3ms - from "0" to "1" 3ms - from "0" to "1" 3ms - from "1" to "0" 3ms Data for selecting an actuator Output voltage - at signal "1" DC 24V Output voltage 1A (max. 1.2A) Lamp load max. 5W per group Switch rate max. - for resistive load - for resistive load 1kHz	Group error display	red F-LED
Input voltage - Rated value - for signal "1" - for signal "0" Input current - for signal "1" Input delay - from "0" to "1" - from "0" to "1" - from "1" to "0" Data for selecting an actuator Output voltage - at signal "1" Cutput current - at signal "1" Rated value Lamp load max. - for resistive load - for resistive load - for resistive load - ot signal "1" Switch rate max. - for resistive load - ot signal "1" - for resistive load - for resistive load - ot signal "1" - for resistive load - for for for for for for for f	Data for selecting a sensor	
- Rated value DC 24V - for signal "1" 15 28.8V - for signal "0" 0 5V Input current 0 5V - for signal "1" 7mA Input delay - from "0" to "1" - from "0" to "1" 3ms - from "1" to "0" 3ms Data for selecting an actuator 0utput voltage - at signal "1" DC 24V Output voltage 0 5V - at signal "1" DC 24V Output current - at signal "1" - at signal "1" DC 24V Output current - at signal "1" - at signal "1" DC 24V Output current - at signal "1" - at signal "1" DC 24V Output current - at signal "1" - at signal "1" DC 24V Switch rate max. - 5W per group Switch rate max. - for resistive load - for resistive load 1kHz - for industring load (#EO 047.5.4. DO 42) 0 EI Hz	Input voltage	
- for signal "1" 15 28.8V - for signal "0" 0 5V Input current 7mA - for signal "1" 7mA Input delay 3ms - from "0" to "1" 3ms - from "1" to "0" 3ms Data for selecting an actuator 0 Output voltage 0 - at signal "1" DC 24V Output current - at signal "1" - at signal "1" DC 24V Output current - at signal "1" - at signal "1" DC 24V Switch rate max. 5W per group - for resistive load 1kHz - for resistive load 0 fl/fz	- Rated value	DC 24V
- for signal "0" 0 5V Input current 7mA - for signal "1" 7mA Input delay 3ms - from "0" to "1" 3ms - from "0" to "1" 3ms - from "1" to "0" 3ms Data for selecting an actuator 0utput voltage - at signal "1" DC 24V Output current - at signal "1" - at signal "1" DC 24V Output current - at signal "1" - at signal "1" DC 24V Switch rate max. 5W per group Switch rate max. - for resistive load - for resistive load 1kHz	- for signal "1"	15 28.8V
Input current - for signal "1" 7mA Input delay - from "0" to "1" 3ms - from "1" to "0" 3ms Data for selecting an actuator Output voltage - at signal "1" DC 24V Output current - at signal "1" DC 24V Output current - at signal "1" 1A (max. 1.2A) Lamp load max. 5W per group Switch rate max. - for resistive load 1kHz	- for signal "0"	0 5V
- for signal "1" 7mA Input delay 3ms - from "0" to "1" 3ms - from "1" to "0" 3ms Data for selecting an actuator 3ms Output voltage - at signal "1" - at signal "1" DC 24V Output current - at signal "1" - at signal "1" DC 24V Output current - at signal "1" - at signal "1" At (max. 1.2A) Lamp load max. 5W per group Switch rate max. - for resistive load - for resistive load 0 film	Input current	
Input delay - from "0" to "1" - from "1" to "0" Data for selecting an actuator Output voltage - at signal "1" Output current - at signal "1" Rated value Lamp load max. Switch rate max. - for resistive load for resi	- for signal "1"	7mA
- from "0" to "1" 3ms - from "1" to "0" 3ms Data for selecting an actuator 3ms Output voltage 0utput voltage - at signal "1" DC 24V Output current 1A (max. 1.2A) Lamp load max. 5W per group Switch rate max. 1kHz - for resistive load 1kHz	Input delay	
- from "1" to "0" 3ms Data for selecting an actuator 0utput voltage - at signal "1" DC 24V Output current - at signal "1" - at signal "1" A (max. 1.2A) Lamp load max. 5W per group Switch rate max. - for resistive load - for resistive load 1kHz	_ from "0" to "1"	3ms
Data for selecting an actuator Output voltage - at signal "1" DC 24V Output current - at signal "1" Rated value 1A (max. 1.2A) Lamp load max. Switch rate max. - for resistive load 1kHz 0 1kHz	- from "1" to "0"	3ms
Output voltage DC 24V - at signal "1" DC 24V Output current - at signal "1" - at signal "1" TA (max. 1.2A) Rated value 1A (max. 1.2A) Lamp load max. 5W per group Switch rate max. - for resistive load - for resistive load 1kHz - for resistive load 0.5Hz	Data for selecting an actuator	
- at signal "1" DC 24V Output current - at signal "1" - at signal "1" TA (max. 1.2A) Rated value 1A (max. 1.2A) Lamp load max. 5W per group Switch rate max. 1kHz - for resistive load 1kHz	Output voltage	
Output current - at signal "1" - at signal "1" 1A (max. 1.2A) Lamp load max. 5W per group Switch rate max. 1kHz - for resistive load 1kHz	- at signal "1"	DC 24V
- at signal "1" Rated value 1A (max. 1.2A) Lamp load max. 5W per group Switch rate max. - for resistive load 1kHz for inductive load (IEO 017 E 1 DO 10)	Output current	
Rated value 1A (max. 1.2A) Lamp load max. 5W per group Switch rate max. 5W per group - for resistive load 1kHz for inducting load (JEO 017.5.1 DO 10) 0.5Hz	- at signal "1"	
Lamp load max. 5W per group Switch rate max. - for resistive load 1kHz for inductive load (IEC 017.5.1.DO 10)	Rated value	1A (max. 1.2A)
Switch rate max. - for resistive load for instructive load (IEC 047.5.1.DC 42)	Lamp load max.	5W per group
- for resistive load 1kHz	Switch rate max.	
for inductive load (IEO 047 5 4 DO 42)	- for resistive load	1kHz
- TOF INDUCTIVE 1080 (IEC 947-5-1, DC 13) U.5HZ	- for inductive load (IEC 947-5-1, DC 13)	0.5Hz
- lamp load 1Hz	- lamp load	1Hz
Limit of the inductive circuit interruption voltage tvp. L+ (-52V)	Limit of the inductive circuit interruption voltage	typ. L+ (-52V)

323-1BH01 - DI 8xDC 24V, DO 8xDC 24V 1A

Order Data DI 8xDC 24V, DO 8xDC 24V 1A VIPA 323-1BH01

Description The module has 16 channels, isolated to the back panel bus, where 8 working as inputs and the 8 working as outputs. The status of the channels is shown via LEDs.

Properties

• 16 channels, from this 8 inputs and 8 outputs

- Nominal input voltage DC 24V
- Supply voltage DC 24V (external) for outputs
- Output current 1A per channel
- LED for error message at overload, overheat or short circuit
- Activity monitoring of the channels via LED

Structure





[1] LEDs

- [2] flap with labeling strip
- [3] contact bar
- [4] flap opened with inner label

Pin assignment Circuit diagram Status monitor

Pin	Assignment	Circuit diagram		LED	Description
1 2	Not used Input I+0.0	234	DI8/DO8xDC24V	1L+	LED (green) supply voltage is on
 9	Input I+0.7	5 6 7 8 7	.1 .2 .3 .4	.07	LED (green)
10	Ground 1M inputs	9	.5		I+0.0 I+0.7
11	Supply voltage	10 1M	.7		Q+0.0 Q+0.7
	DC +24V	1 <u>1_2L+</u> 1 <u>2</u>	SM323		At signal "1" (input)
12	Output Q+0.0	13 			res. active output,
					the according LED
19	Output Q+0.7		.2		is activated
20	Ground 2M outputs		.4		
		19 20 2M		F	LED (red) error at overload, short circuit

Schematic diagram





Module name	VIPA 323-1BH01
Dimensions and Weight	
Dimensions WxHxD	40x125x120mm
Weight	210g
Data for specific module	
Number of Inputs	8
Number of Outputs	8
Programming specifications	
Input data	1Bvte
Output data	1Bvte
Voltages, Currents, Potentials	
Rated load voltage L+	DC 24V
Isolation	
- between channels and backplane bus	ves
Isolation tested with	DC 500V
Current consumption	
- from the backplane bus	70mA
- from load voltage L+ (without load)	15mA
Power dissipation of the module	4W
Status, Interrupts, Diagnostics	
Status display	green LED per channel
Group error display	red F-LED
Data for selecting a sensor	
Input voltage	
- Rated value	DC 24V
- for signal "1"	15 28.8V
- for signal "0"	0 5V
Input current	
- for signal "1"	7mA
Input delay	
- from "0" to "1"	3ms
- from "1" to "0"	3ms
Connection of 2-wire-BEROs	possible
- Permitted bias current	1.5mA
Data for selecting an actuator	
Output voltage	
- at signal "1"	DC 24V
Output current	
- at signal "1"	
Rated value	1A (max. 1.2A)
Lamp load max.	5W per channel
Switch rate max.	
- for resistive load	1kHz
- for inductive load (IEC 947-5-1, DC 13)	0.5Hz
- lamp load	1Hz
Limit of the inductive circuit interruption voltage	typ. L+ (-52V)

323-1BL00 - DI 16xDC 24V, DO 16xDC 24V 1A

Order Data DI 16xDC24V, DO 16xDC24V 1A VIPA 323-1BL00

Description The module has 32 channels, isolated to the back plane bus, with 16 inputs and 16 outputs. The status of the channels is shown via LEDs.

- 32 channels, 16 inputs and 16 outputs
 - Nominal input voltage DC 24V
 - Supply voltage DC 24V (external) for outputs
 - Output current 1A per channel
 - LED for error message at overload, overheat or short circuit
 - Activity monitoring of the channels via LED

Structure

Properties





- [1] LEDs
- [2] flap with labeling strip
- [3] contact bar
- [4] flap opened with inner label

Pin assignment Circuit diagram Status monitor

Pin	Assignment	Circuit diagram		LED	Description
1	Not used	2 <u>2</u> 2 2 2 2 2 2 2 2 2 2 2 2 2 2 1 2L+	DIO 32xDC24V +0 +0 +0 1L+	1L+, 2L+	LED (green)
2 	Input I+0.0				supply voltage is on
19	Input I+1.7	$\begin{array}{c} \underline{6} \\ 7 \end{array}$.3	.07	LED (green)
20	Ground 1M inputs		.5		I+0.0 I+1.7
21, 31	Supply voltage DC +24V				Q+0.0 Q+1.7
22	Output Q+0.0	3 <u>1</u> 3L+			res. active output.
		12 - 32 - 32 - 13 - 33 - 13 - 33 - 13 - 1	.0		the according LED
39	Output Q+1.7		.2		is activated
30	Ground 2M outputs	16 36 37 37	.4		
40	Ground 3M outputs			F	LED (red)
		$\begin{array}{c c} 19 \\ \hline 20 \\ 1M \end{array} \begin{array}{c} 39 \\ \hline 40 \\ 3M \end{array}$	X 2/3 4 F ↓ VIPA 323-1BL00 IN OUT		error at overload, short circuit

Schematic diagram





Module name	VIPA 323-1BL00
Dimensions and Weight	
Dimensions WxHxD	40x125x120mm
Weight	210g
Data for specific module	
Number of Inputs	16
Number of Outputs	16
Programming specifications	
Input data	2Bvte
Output data	2Byte
Voltages Currents Potentials	
Rated load voltage L+	DC 24V
Isolation	50211
- between channels and backplane bus	Ves
Isolation tested with	DC 500V
	200001
- from the backplane bus	130mA
- from load voltage L + (without load)	30mA
Power dissipation of the module	5.8W
Status Interrupts Diagnostics	3.011
Status, interrupts, Diagnostics	green I ED per channel
Croup error diaplay	
Data for solocting a sonsor	IEU F-LED
Pated value	
for signal "1"	
for signal "0"	0 51/
	05V
for signal "1"	7mΔ
- from "0" to "1"	3ms
- from "1" to "0"	3ms
Connection of 2 wire BEPOs	nossible
- Permitted bias current	1 5mΔ
Data for selecting an actuator	1.011/4
- at signal "1"	
	00 241
- at signal "1"	
Pated value	14 (may 124)
Lamp load may	5W per group
Switch rate may	
- for resistive load	1647
- for inductive load (IEC 947-5-1 DC 13)	0.5Hz
- lamp load	147
Limit of the inductive circuit interruption voltage	typ 1 + (52)/)
	ιyp. L ⁺ (-32ν)

Chapter 6 Analog Input Modules

Outline This chapter contains a description of the structure and the operation of the VIPA analog input modules.

System overview

Input modules SM 331

The following gives you an overview of the analog input modules of the System 300V available from VIPA:



Order Data Analog input modules

Туре	Order number	Page
AI 8x13Bit, U, I, R,	VIPA 331-1KF01	6-7
Thermo, Pt/Ni100, Ni1000		
AI 2x12Bit, U, I, R,	VIPA 331-7KB01	6-17
Thermo, Pt/Ni100		
AI 8x12Bit, U, I, R,	VIPA 331-7KF01	6-17
Thermo, Pt/Ni100		

Security hint



Attention!

Please regard that the modules described here do not have hardware precautions against wrong parameterization res. wrong wiring. The setting of the according measuring range is exclusively at the project engineering.

For example, the modules may get a defect if you connect a voltage at parameterized current measuring.

At the project engineering you should be very careful.

Please regard also that disconnecting res. connecting during operation is not possible!

Principles	
Cables for analog signals	For analog signals you have to use isolated cables to reduce interference. The cable screening should be grounded at both ends. If there are differences in the potential between the cable ends, there may occur a potential compensating current that could disturb the analog signals. In this case you should ground the cable screening only at one end.
Connecting test probes	 The analog input modules provide variant connecting possibilities for: Current sensor Voltage senor Resistance thermometer Thermocouple Resistors
	Note! Please take care of the correct polarity when installing the measuring transducer! Please install short circuits at non-used inputs by connecting the positive contact with the channel ground of the according channel.
Parameterization	The analog input modules from VIPA do not have any measuring range plug. The modules are parameterized via the hardware configurator or during runtime via SFCs.
Diagnostic functions	 The modules that are described in this chapter except the 331-1KF01 offer diagnostics functions. The following errors may cause diagnostics: Error in the project engineering res. parameterization Wire break at current measuring Measuring range overstep Measuring range shortfall Common Mode Error Lost process interrupt Failure of the external power supply For diagnostic evaluation during runtime, you may use the SFCs 51 and 59. They allow you to request detailed diagnostic information and to react
	to it.

Parameterization - Basics

Overview	 The analog input modules from VIPA do not have any measuring range plug, so the measuring range is to be set by configuration. There are the following possibilities for parameterization: Parameterization by hardware configuration of Siemens SIMATIC manager or with WinPLC7 from VIPA. Parameterization during run time by means of SFCs.
Parameterization by hardware configuration	 To be compatible to the Siemens SIMATIC manager the following steps are to be accomplished: Start the hardware configurator from Siemens Create a new project Configure your CPU. Link-up your System 300V modules in the plugged-in sequence starting with slot 4. Here the analog input modules of VIPA are to be projected as analog input modules of Siemens: The analog input modules can be found at the hardware catalog at <i>SIMATIC 300 > SM-300</i>. If needed parameterize the CPU respectively the modules. The parameter window appears as soon as you double click on the according module. At this window the according parameter can be changed. Save your project, switch the CPU to STOP and transfer your project to the CPU. As soon as the CPU is switched to RUN the parameters are transferred to the connected modules.
Parameters	 The following parameters can be adjusted at the analog input modules: Starting address of the input data Measuring range, measuring type and integration time Diagnostics and interrupt reaction (only 331-7Kx01)

Parameterization during runtime

By using the SFCs 55, 56 and 57 you may change the parameters of the analog modules during runtime via the CPU. The time needed until the new parameterization is valid can last up to a few ms. During this time the measuring value 7FFFh is issued.

The following example shows the assignment of record set 1 to the module 331-7Kx01 during run time.

Example

Var	
rec1	

rec1	array [013] of BYTE
retval	INT
busy	BOOL

Set Record set 1:

L	B#16#0	//Diagnostic disabled
Т	#rec1[0]	
L	B#16#AA	//Interference freq. suppression
Т	#rec1[1]	
L	B#16#D4	//Meas. range Type S: 0100b
Т	#rec1[2]	//Meas. type: Thermocouple
Т	#rec1[3]	//Compensation internal: 1101b
Т	#rec1[4]	//for all channels
Т	#rec1[5]	
L	B#16#7F	//Upper limit value
Т	#rec1[6]	//channel 0: 7FFFh
L	B#16#FF	
Т	#rec1[7]	
	:	
L	B#16#80	//Upper limit value
Т	#rec1[10]	//channel 2: 8000h
L	B#16#00	
-		

T #rec1[11]

Record set 1 from module 331-7Kx01:		
Byte	Bit 7 Bit 0	
0	Bit 5 0: reserved	
	Bit 6: Diagnosis interrupt release	
	Bit 7: Proc. interrupt release	
1	Interference freq. suppression	
	Bit 0, 1: Channel 0/1	
	Bit 2, 3: Channel 2/3	
	Bit 4, 5: Channel 4/5	
	Bit 6, 7: Channel 6/7	
2	Mode Channel 0/1	
	Bit 3 0: Measuring range	
	Bit 7 4: Measuring type	
3	Mode Channel 2/3	
	Bit 3 0: Measuring range	
	Bit 7 4: Measuring type	
4	Mode Channel 4/5	
	Bit 3 0: Measuring range	
	Bit 7 4: Measuring type	
5	Node Channel 6/7	
	Bit 7 0. Measuring tange	
6.7	Bit 7 4. Measuring type	
0,7		
ð, 9		
10, 11	Upper limit value Channel 2	
12, 13	Lower limit value Channel 2	

Transfer with SFC 55 "WR_PARM" Record set 1to Module:

Call "WR	_PARM"	//call SFC 55
REQ	:=TRUE	//write request
IOID	:=B#16#54	//identifier for the address space: peripheral input
LADDR	:=W#16#100	//logical base address: 100
RECNUM	:=B#16#1	//record number 1
RECORD	:=#rec1	//record for Record set 1
RET_VAL	:=#retval	//return value (0: no error >0: error code)
BUSY	:=#busy	//BUSY = 1: the write operation has not been completed

Get mode As shown in the following illustration the parameter *mode* is made up of the coding of the *measuring range* and *measuring type* during run time parameterization each channel respectively channel group.



The corresponding codes can be found at *parameterization* of each module.

The table is divided into *measuring type* like voltage, current, resistance measuring... . Here the corresponding binary code of the *measuring type* may be found.

Within the *measuring types* there are the *measuring ranges*, for which a binary *measuring range code* is to be specified in each case.

Example Referring to the example specified above the mode is determined in the following:

Given: Measuring type: Thermocouple, compensation internal, linear Measuring range: Type S

For the module 331-7Kx01 results from the table in the case of "Thermocouple with compensation internal, linear" the binary coding for measuring type: 1101b.

For Measuring range "Type S" the binary measuring range coding results as: 0100b.

By joining the two binary values you receive the following byte as *mode*: $1101\ 0100b = D4h$.
331-1KF01 - AI 8x13Bit

Order data	AI 8x13Bit	VIPA 331-1KF01
Description	The analog input module tradigital signals for the international terms. The module is pin and fur Siemens. Plugging and unple Voltage and current encode connected as sensors	ansforms analog signals from the process into I processing. nction compatible to the known module from ugging during operation, is not supported. rs, resistors and resistor thermometers may be
Properties	 8 inputs Measuring value resolutio Isolated to the backplane	on 12bit + sign bus
Default configuration	After Power ON the module can be changed by hardware	has the following default configuration. These e configuration.

- measuring range: ±10V for all channels
- integration time: 60ms

Structure





- [1] LEDs (not active)
- [2] flap with labeling strip
- [3] contact bar
- [4] flap opened with inner label

SM331

Pin assignment

Pin	Assignment	Connection
1	U+ channel 0	<u>1 U+</u>
2	I+ channel 0	<u>2 I+</u>
3	S- channel 0	CH 0 <u>3 S-</u>
4	M+ channel 0	<u>4 M+</u>
5	M- channel 0	<u>5 M-</u>
6	U+ channel 1	<u>6 U+</u>
7	I+ channel 1	<u>7 I+</u>
8	S- channel 1	CH 1 8 S-
9	M+ channel 1	<u>9 M+</u>
10	M- channel 1	<u>10 M-</u>
11	U+ channel 2	<u>11 U+</u>
12	I+ channel 2	<u>12 ⁺</u>
13	S- channel 2	CH 2 <u>13</u> S-
14	M+ channel 2	<u>14 M+</u>
15	M- channel 2	<u>15 ^{M-}</u>
16	U+ channel 3	<u>16 U+</u>
17	I+ channel 3	<u>17 ⁺</u>
18	S- channel 3	CH 3 <u>18 S-</u>
19	M+ channel 3	19 M+
20	M- channel 3	<u>20 M-</u>
21	U+ channel 4	<u>21 U+</u>
22	I+ channel 4	<u>22 +</u>
23	S- channel 4	CH 4 23 S-
24	M+ channel 4	<u>24 M+</u>
25	M- channel 4	<u>25 M-</u>
26	U+ channel 5	<u>26 U+</u>
27	I+ channel 5	<u>27 +</u>
28	S- channel 5	CH 5 28 S-
29	M+ channel 5	<u>29 M+</u>
30	M- channel 5	30 M-
31	U+ channel 6	<u>31 U+</u>
32	I+ channel 6	<u>32 +</u>
33	S- channel 6	CH 6 <u>33</u> S-
34	M+ channel 6	<u>34 M+</u>
35	M- channel 6	<u>35 M-</u>
36	U+ channel 7	<u>36 U+</u>
37	I+ channel 7	<u>37 +</u>
38	S- channel 7	CH 7 <u>38 S-</u>
39	M+ channel 7	39 M+
40	M- channel 7	<u>40 M-</u>



Wiring diagrams

The following illustration shows the connection options for the different measuring ranges. The assignment to the measuring ranges is to find in the column "Conn." of the table "Measuring" on the next pages.





Note!

Please take care that the maximum permissible common-mode voltage of 2V between the inputs at connection of voltage and current giver is not exceeded. To avoid wrong measurements you connect the individual connections M- with each other.

At measuring of resistances and resistance thermometers a connection of the M- connections is not required.

Temporarily not used inputs with activated channel must be connected with the concerning ground. When not used channels are deactivated this is not necessary.

Representation of analog values Analog values are exclusively processed by the CPU in a binary format. For this the analog module transforms every process signal into a digital and transfers this as word to the CPU.

At similar nominal range, the digitalized analog value for in- and output is identical.

ResolutionBecause the resolution of the module is 12Bit plus sign-Bit, the not used low
value positions (3 Bit) are filled with "0".For the sign Bit is valid:
Bit 15 = "0" \rightarrow positive value

Bit 15 = "1" \rightarrow negative value

Resolution			Analog value													
			High byte Low byte													
Bit number	15	14	4 13 12 11 10 9 8 7 6 5 4 3 2 1					1	0							
Value	SG	2 ¹⁴	2 ¹³	2 ¹²	2 ¹¹	2 ¹⁰	2 ⁹	2 ⁸	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
12bit + sign	SG		Measuring value							0	0	0				

331-1KF01 - AI 8x13Bit - Parameterization

Overview	After Power ON the module is set to $\pm 10V$ for all channels with an integration time of 60ms.
	Via a hardware configuration you may parameterize the channels individually.
Place module	• Start the hardware configurator with the project the analog modules are to be configured.
	• To place the analog module open the hardware catalog. There the module can be found at SIMATIC 300/SM-300/AI-300, order no.: 6ES7 331-1KF01-0AB0.
	• Choose the according module and drag & drop it to the concerning slot in the hardware configurator.
Parameterize the module	Via double click on the wanted module in the hardware configurator you open the concerning parameter window. You may alter the following parameters: • Start address of the data of the module stored in the CPU
	 Measuring range, measuring type and integration times for all of the 8 channels
Save and transfer	Save and compile your project
project	Set your CPU to STOP
	 Transfer your project into the CPU
	As soon as you switch the CPU into RUN, the parameters are transmitted to the analog input module.
	More detailed information about the parameters can be found on the following pages.

Structure of parameter byte (Record set 1)

At the parameterization, a parameter area of 14byte length is stored in the record set 1. Under deploying the SFCs 55, 56 and 57, you may alter the parameters during run time and transfer them to your analog module.

Record set 1 (Byte 0 to 13):

Byte	Bit 7 Bit 0							
0	Temperature measuring:	0000 00	00b: Grad Celsius					
		0000 10	0000 1000b: Grad Fahrenheit					
		0001 00	00b: Kelvin					
1	Interference frequency supp	oression:						
	0000 0001D: 60Hz (50ms Ir	itegration tim	<i>e)</i>					
2	Mode channel 0	ilegration tim	e)					
2	Rit 3 0: Measuring range							
	Bit 7 4: Measuring type							
3	Mode channel 1							
Ŭ	Bit 3 0: Measuring range		7 4 3	0 Bit-No.				
	Bit 7 4: Measuring type	Byte 29						
4	Mode channel 2		Coding for Coding t	—				
	Bit 3 0: Measuring range		measuring type measuri	ng range				
	Bit 7 4: Measuring type							
5	Mode channel 3							
	Bit 3 0: Measuring range	The ac	cording coding of i	measuring				
	Bit 7 4: Measuring type	range	and measuring typ	e is des				
6	Mode channel 4	cribed o	on the following page	es.				
	Bit 3 0: Measuring range	To dea	activate a channel	the code				
7	Bit 7 4: Measuring type	0000 00	000 is used.	_				
1	Rit 2 O: Mocouring range							
	Bit 7 <i>A</i> : Measuring type							
8	Mode channel 6			-				
U	Bit 3 0. Measuring range							
	Bit 7 4: Measuring type							
9	Mode channel 7							
	Bit 3 0: Measuring range							
	Bit 7 4: Measuring type							
10	Temperature coefficient:	At temperati	ire measurement a	temne-				
	Bit 3 0: channel 1	rature coeffic	cient is required. T	he table				
	Bit 7 4: channel 0	shows the ac	cording coefficient:					
11	Temperature coefficient:		_					
	Bit 3 0: channel 3	Measurem.	Temperature	Coding				
10	Bit 7 4: Channel 2	range	coefficient	each				
12	Rit 3 O: chapped 5	Pt 100	Pt 0.003850Ω/Ω/°C	0100b				
	Rit 7 4: channel 4		(ITS-90)					
13	Temperature coefficient:	NI:100		1000h				
10	Bit 3 0: channel 7	Ni1000	NI 0.0001002/22/ C	10000				
	Bit 7 4: channel 6							
		LG-Ni 1000	Ni 0.005000Ω/Ω/°C	1010b				

Mode per Channel

	7		4	3		0	Bit-No
Byte 29							
				L			
	Coding for measuring type			Co m			

The following section shows an overview of all measuring types and ranges plus binary coding for the parameterization. Additionally, the wiring diagram assigned to the measuring range is shown in brackets.



modeling (po volage modeling (modeling cpo ocanigi oco is

Measuring range (Connection)	Measuring rar	nge / Representation		Measuring range coding
+/- 50mV	58.79mV	= End Overdrive region	(32511)	
(Connection 3)	- 5050mV	= Nominal range	(-2764827648)	0001b
(,	- 58.79mV	= End Underdrive region	(-32512)	
+/- 500mV	587.9mV	= End Overdrive region	(32511)	
(Connection 3)	- 500500mV	= Nominal range	(-2764827648)	0011b
	- 587.9mV	= End Underdrive region	(-32512)	
+/- 1V	1.176V	= End Overdrive region	(32511)	
(Connection 3)	- 11V	= Nominal range	(-2764827648)	0100b
	- 1.175V	= End Underdrive region	(-32512)	
+/- 5V	5.879V	= End Overdrive region	(32511)	
(Connection 1)	- 55V	= Nominal range	(-2764827648)	0110b
	- 5.879V	= End Underdrive region	(-32512)	
1 5V	5.704V	= End Overdrive region	(32511)	
(Connection 1)	15V	= Nominal range	(027648)	0111b
	0.296V	= End Underdrive region	(- 4864)	
0 10V	11.759V	= End Overdrive region	(32511)	
(Connection 1)	010V	= Nominal range	(027648)	1000b
	-1.759V	= End Underdrive region	(- 4864)	
+/- 10V	11.759V	= End Overdrive region	(32511)	
(Connection 1)	- 1010V	= Nominal range	(-2764827648)	1001b
	- 11.759V	= End Underdrive region	(-32512)	

Measuring type Current measuring (Measuring type coding: 0010b)

Measuring range (Connection)	Measuring range	Measuring range coding		
0 20mA	23.52mA	= End Overdrive region	(32511)	
(Connection 2)	020mA	= Nominal range	(027648)	0010b
	- 3.52mA	= End Underdrive region	(-4864)	
4 20mA	22.81mA	= End Overdrive region	(32511)	
(Connection 2)	420mA	= Nominal range	(027648)	0011b
. , , ,	1.185mA	= End Underdrive region	(-4864)	
+/- 20mA	23.52mA	= End Overdrive region	(32511)	
(Connection 2)	- 2020mA	= Nominal range	(-2764827648)	0100b
	- 23.52mA	= End Underdrive region	(-32512)	

Measuring type Resistance measuring (Measuring type coding: 0101b)

Measuring range	Measuring range	Measuring range		
(Connection)	measuring range	coding		
600 Ohm	705.53 Ohm	= End Overdrive region	(32511)	
(Connect. 4, 5, 6)	0600 Ohm	= Nominal range	(027648)	0110b
	negative values	physically not possible		
6000 Ohm	7055.3 Ohm	= End Overdrive region	(32511)	
(Connect. 4, 5, 6)	06000 Ohm	= Nominal range	(027648)	1000b
	negative values			

Measuring type Thermo resistance measuring (Measuring type coding: 1001b), wiring diagram (Conn.: 4, 5, 6)

Meas. range	°C (0.1°C/digit)	Unit dec.	°F (0.1°F/digit)	Unit dec.	K (0.1K/digit)	Unit dec.	Range	Range coding
	1000.0	10000	1832.0	18320	1273.2	12732	End Overdrive region	
Pt100 Standard	850.0	8500	1562	15620	1123.2	11232	Nominal	00106
Otandard	-200.0	-2000	 -328.0	-3280	 73.2	732	range	00100
	-243.0	-2430	-405.4	-4054	30.2	302	End Under- drive region	
Meas. range	°C (0.01°C/digit)	Unit dec.	°F (0.01°F/digit)	Unit dec.			Range	Range coding
	155.00	15500	311.00	31100	-	-	End Overdrive region	2
Pt100 Climate	130.00	13000	266.00	26600			Nominal	00006
Climate	-120.00	-12000	 -184.00	-18400	-	-	range	00000
	-145.00	-14500	-229.00	-22900	-	-	End Under- drive region	
Meas. range	°C (0.1°C/digit)	Unit dec.	°F (0.1°F/digit)	Unit dec.	K (0.1K/digit)	Unit dec.	Range	Range coding
	295.0	2950	563.0	5630	568.2	5682	End Overdrive region	
Ni100 Standard	250.0	2500	4820	4820	523.2	5232	Nominal	00115
Stanuaru	-60.0	-600	-76.0	-760	 213.2	2132	range	00110
	-105.0	-1050	-157.0	-1570	168.2	1682	End Under- drive region	
Meas. range	°C (0.01°C/digit)	Unit dec.	°F (0.01°F/digit)	Unit dec.			Range	Range coding
	295.00	29500	327.66	32766	-	-	End Overdrive region	
Ni100 Climate	250.00	25000	280.00	28000	_	-	Nominal	0001b
Chinato	-60.00	-6000	-76.00	7600			range	00010
	-105.00	-10500	-157.00	-15700	-	-	drive region	
Meas. range	°C (0.1°C/digit)	Unit dec.	°F (0.1°F/digit)	Unit dec.	K (0.1K/digit)	Unit dec.	Range	Range coding
	295.0	2950	563.0	5630	568.2	5682	End Overdrive region	
Ni 1000 / LG-Ni 1000	250.0	2500	482.0	4820	523.2	5232	Nominal	01105
Standard	-60.0	-600	-76.0	-760	 213.2	2132	range	0110b
	-105.0	-1050	-157.0	-1570	168.2	1682	End Under- drive region	
Meas. range	°C (0.01°C/digit)	Unit dec.	°F (0.01°F/digit)	Unit dec.			Range	Range coding
	295.00	29500	327.66	32766	-	-	End Overdrive region	
Ni 1000 / I G-Ni 1000	250.00	25000	280.00	28000			Nominal	
Climate	 -60.00	 -6000	 -76.00	 7600	-	-	range	1010b
	-105.00	-10500	-157.00	-15700	-	-	End Under- drive region	

When exceeding the overdrive region 32767 (7FFFh) is issued, falling below the underdrive region -32768 (8000h) is issued.

331-1KF01 - AI 8x13Bit - Technical Data

Module name	VIPA 331-1KF01			
Dimensions and Weight				
Dimensions (WxHxD in mm)	40x125x120			
Weight	ca. 2	05g		
Data for specific module				
Number of inputs	8			
- for 4wire resistance-type sensor	8			
Length of cable				
- shielded	200m / 50m at meas	suring range ±50mV		
Programming specifications				
Input data	8wo	rds		
Parameter data	14b	yte		
Diagnostic data	-			
Voltages, Currents, Potentials				
Constant current for resistance-type sensor				
- resistance thermometer and	0.83	mA		
resistance measurement 0 600Ω				
- resistance measurement 0 6k Ω	0.25mA			
Isolation				
 between channels and backplane bus 	yes			
- between the channels	no			
Permitted potential difference				
- between the inputs (U_{CM})	DC	2V		
- between the inputs and M_{INTERN} (U _{ISO})	DC 75V /	AC 60V		
Isolation tested with	DC 5	00V		
Current consumption				
- from the backplane bus	200	mA		
Power dissipation of the module	1.0	W		
Analog value generation				
Measuring principle	Sigma delta			
Integration time / conversion time / resolution				
(per channel)				
- programmable	ye	S		
- Integration time in ms	60ms	50ms		
- Basic conversion time in ms	61ms	51ms		
additional conversion time for	61ms 51ms			
measuring resistance in ms				
- Resolution Incl. overrange	13Bit			

Analog value generation	VIPA 331-1KF01			
- Noise suppression for frequency f1 in Hz	50Hz	0Hz		
 Basic execution time of the module in ms (all channels released) 	488ms)8ms		
 Basic execution time of the module in ms (all channels for measuring resistance enabled) 	976ms	8′	16ms	
Suppression of interference, limits error				
Noises suppression for f=n x (f1 ±1%) (f1=interferer	nce frequency, n=1,2,)		
- Common-mode interference ($U_{CM} < 2V$)	> 80	6dB		
 Series-mode noise (peak value of noise < nominal value of input range 	> 4(0dB		
Crosstalk between the inputs	> 50	0dB		
Operational limit (in the entire temperature range, w	with reference to the inp	ut range)		
	Measuring rang	ge	Tolerance	
- Voltage input	±50mV, ±500mV,	±1V	±0.5%	
	±5V, 15V, ±10V, 0	010V	±0.6%	
- Current input	±20mA, 020mA, 4	±0.5%		
- Resistors	0600Ω, 06k	±0.5%		
- Resistance thermometer	Pt100		±1.2K	
	Ni100, Ni1000, LG-	Ni1000	±1.0K	
Basic error (operational limit at 25°C referred to the	input range)			
	Measuring ran	ige	Tolerance	
- Voltage input	±50mV, ±500mV	, ±1V	±0.3%	
	±5V, 15V, ±10V,	010V	±0.4%	
- Current input	±20mA, 020mA, 4	I20mA	±0.3%	
- Resistors	0600Ω, 06	kΩ	±0.3%	
- Resistance thermometer	Pt100		±0.8K	
	Ni100, Ni1000, LG·	-Ni1000	±0.8K	
Temperature error (with reference to the input range)	±0.00	5%/K		
Linearity error (with reference to the input range)	±0.0)2%		
Repeatability (in steady state at 25°C, with reference to the input range)	±0.0)5%		
Status, Interrupts, Diagnostics				
Diagnostic functions	n	0		

Data for selecting a sensor	VIPA 331-1KF01			
	Input range	Input resistance		
- Voltage	± 50mV, ± 500mV, ± 1V	100MΩ		
	±5V, 15V, ±10V, 010V	100kΩ		
- Current	±20mA, 020mA, 420mA	100Ω		
- Resistors	0 600Ω, 0 6kΩ	100MΩ		
- Resistance thermometer	Pt100 Standard / Climate	100MΩ		
	Ni100, Ni1000, LG-Ni1000 Standard / Climate	100MΩ		
Maximum input voltage for voltage input U+ (destruction limit)	max. 30V			
Maximum input voltage for voltage	max. 12V			
input M+ (destruction limit)	30V for max. 1s			
Maximum input current for current input L+ (destruction limit)	40mA			
Connection of the sensors				
 for measuring voltage 	possible			
- for measuring current				
as 2wire transmitter	possible, with external supply			
as 4wire transmitter	possible			
 for measuring resistance 				
with 2conductor connection	possible			
with 3conductor connection	possible			
with 4conductor connection	possible			
Characteristic linearization	yes			
- for RTD	Pt100 Standard / Climate			
	Ni100, Ni1000, LG-Ni1000 Standard / Climate			
Technical unit for temperature measurement	°C/K/F			

331-7Kx01 - AI 8(2)x12Bit

Order data	AI 8x12Bit AI 2x12Bit	VIPA 331-7KF01 VIPA 331-7KB01	
Description	The analog input modules t digital signals for the interna compatible to the modules fr Please regard that contrary here do not have any measu measuring range exclusive engineering. Plugging and of Voltage and current sense thermometers may be conner	ransform analog sig l processing. The m om Siemens with th to the Siemens mod uring range plug. Th vely takes place unplugging during o ors, thermocouples ected.	gnals from the process into nodules are pin and function he same name. dules the modules specified he attitude of the designated during software project operation, is not supported. a, resistors and resistance
Properties	 8 inputs in 4 channel grou 2 inputs in 1 channel grou Measuring value resolutio Configurable diagnostic a Isolated to the backplane 	ip (331-7KF01) ip (331-7KB01) in 14Bit + sign nd process interrup bus	t
Measuring range after Power ON	After Power ON both mod These can be changed by ha • measuring range: ±10V fo • integration time: 20ms • Interrupts deactivated	ules have the follo ardware configuration or all channels	owing default configuration. on:
Structure			[1] LEDs[2] flap with labeling strip[3] contact bar

₿

110

[4] flap opened with inner label

Nain

Pin assignment status monitor



Connection of sensors Regarding the fact, that parameterized inputs can be left unused due to the building of channel groups, you have to connect the unused inputs with the associated ground.

If you want to use the internal compensation when deploying thermocouples, the 2 COMP inputs have to be bridged too.

In the following all connection types of sensors for a pair of channels are specified.

Installation of Current sensors as 2wire or 4wire measuring transducer

current sensors The 2wire measuring transducer gets the supply voltage (13V at 30mA) short-circuit resistant via the clamps of the analog input module. The 2wire measuring transducer transduces the measuring value into a current. With use of 2wire measuring transducer with a voltage >13V you may connect in line an external power supply. But here you have to deactivate the internal power supply, by selecting 4wire operation during hardware configuration.

2wire measuring
transducerThe following picture illustrates the connection of 2wire measuring
transducers with internal respectively external power supply:



4wire measuring transducer

Please regard that the 4wire measuring transducers have to be provided external.



Installation of voltage sensors

The following picture shows the installation of voltage sensors at a channel pair of a potential separated analog input module:



M+: measuring line (positive) M-: measuring line (negative) Installation of
thermocouplesThe thermo pair consists of two wires of different metals or metal alloys
which are soldered or welded together at the ends. The different combi-
nations of metals cause different thermocouple types, e.g. K, J, N.

Operating basics Independent from the type of the thermocouple the principle of measuring is identical for all types: When the measuring point has another temperature than the free ends of the thermo pair (connection point), a voltage occurs between the free ends, the thermo voltage. The amount of the thermo voltage depends on the difference between the temperature at the measuring point and the temperature at the free ends. For a thermo pair always records a temperature difference, the free ends have to be set on a comparison point with known temperature, to determine the temperature at the measuring point.

Extension to a comparison point The thermo pairs may be extended from your connecting point to a point with known temperature (comparison point) via compensating lines. The compensating lines have the same material as the wires of the thermocouple. The leads are out of copper. In this case you should use the external compensation. Please regard pole correct installation, for this may cause enormous measuring errors.

Installation variants The following pictures show the different installation possibilities of thermocouple with and without compensation slot.

Thermocouples without compensation slotThermocouples without compensation slotand internal compensationand external compensation



M+: measuring line (positive) M-: measuring line (negative) COMP+: Compensation connection (positive) COMP-: Compensation connection (negative)

When connecting thermocouples without compensation slot and parameterized internal compensation, the temperature compensation happens via a temperature sensor in the module per channel pair. At external compensation, thermocouples with integrated compensation have to be used.

Thermocouples with compensation slot



When connecting thermocouples with one compensation slot, you have to regard that the thermocouples have the same type.

The compensation slot is to be connected at COMP+ and COMP- and is to be supplied external.

Installation of resistance thermometers and resistors

The installation of resistance thermometers/resistors needs 4wires. Via the connections I_{C^+} and I_{C^-} the resistance thermometer/resistor gets a constant current. The voltage occurring at the resistor thermometer/resistor is measured via the connections M+ and M-.



- M+: measuring line (positive)
- M-: measuring line (negative)
- I_{C+}: constant current line (positive)
- I_{C-}: constant current line (negative)

By appropriate bridges on the module between M+ and I_{C+} respectively Mand I_{C-} you can attach also resistance thermometers in 2- and 3wire technique. Due to the not considered conduit length you have to count on losses of accuracy with the result of the measurement.

Channel allocation At "resistance thermometers-/resistors measuring" the whole channel group (both channels) are used. The measured value can be found at the area of the 1. channel of the group. The 2. channel of the group is predefined with the overflow value "7FFFh".

Thermocouples with Pt100 reference junction (since firmware V1.3.8) Starting with firmware version 1.3.8 of the analog module, there is the possibility to connect a Pt100 reference junction for compensation.

With this connection variant the temperature of the reference junction is evaluated by means of a Pt100 resistance thermometer. For this the channel group tied up to Pt100 reference junction is to be parameterized as "Pt100 reference junction". Only one channel group may be parameterized as "Pt100 reference junction".

Every channel, which is parameterized on "thermocouple with external compensation", uses the temperature of the Pt100 reference junction for evaluation.

Compared to the compensating box there is the possibility to use thermocouples of different type at the same time. The temperature evaluation is more exactly than internal compensation, too.

Since this variant is not supported by the Siemens SIMATIC manager, the parameterization only takes place exclusively at run time.



M+: measuring line (positive)

M-: measuring line (negative)

I_{C+}: constant current line (positive)

I_{C-}: constant current line (negative)

*) With a wire break at the Pt100 reference junction for evaluation, the 1. channel of one group shows the value 7FFFh.

Connection Pt100 The installation of the Pt100 reference junction needs 4 wires. By appropriate bridges on the module between M+ and I_{C+} respectively M- and I_{C-} you also may attach Pt100 in 2- and 3wire technique. Due to the not considered conduit length you have to count on losses of accuracy with the result of the measurement.

Here via the connections I_{C+} and I_{C-} the Pt resistance thermometer gets a constant current. The voltage occurring at the Pt100 resistor thermometer is measured via the connections M+ and M-.

Channel allocation At Pt100 reference junction the whole channel group (both channels) are used. The measured value can be found at the area of the 1. channel of the group. The 2. channel of the group is predefined with the overflow value "7FFFh". Every channel, which is parameterized on "thermocouple with external compensation", uses this measuring value for evaluation even in a case of a wire break it contains the value 7FFFh. Analog valueThe analog values are only processed by the CPU in binary representation.representationHereby the process signals are transformed into digital format in the analog
module and passed on to the CPU as word variable.

The digitized analog value is the same for input and output values at the same nominal range.

Resolution The resolution of an analog value is 14 Bit plus sign Bit. Bit 15 serves as sign bit (SG) with the meaning:

Bit 15 = "0" \rightarrow positive value

Bit 15 = "1" \rightarrow negative value

Depending upon parameterized interference frequency (integration time) the modules offers different resolutions. The not used low byte bits are set to "0".

Resolution		Analog value														
	High byte Low byte															
Bit number	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Value	SG	2 ¹⁴	2 ¹³	2 ¹²	2 ¹¹	2 ¹⁰	2 ⁹	2 ⁸	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
14bit + sign	SG	G Measuring value (interference frequency 10Hz)								0						
12bit + sign	SG	G Measuring value (interference frequency 50, 60Hz) 0 0 0							0							
9bit + sign	SG	Mea (inte	suring rferei	g valu nce fr	ie eque	ncy 4	00Hz)			0	0	0	0	0	0



Note!

This resolution does not apply to temperature levels. The converted temperature levels are the result of a conversion of the analog module.

Behavior at over-	As soon as a measured value exceeds the ov	verdrive region and/or falls
and underflow	below the underdrive region, the following value	is issued:
	Measuring value > end of overdrive region:	32767 (7FFFh)
	Measuring value < end of underdrive region:	-32768 (8000h)

331-7Kx01 - AI 8(2)x12Bit - Parameterization

Overview	After power ON every channel of the modules is adjusted to $\pm 10V$ with an interference frequency of 50Hz. The diagnostic function is deactivated. At the parameterization, a record set of 16byte length is transferred to both modules. Here the AI 2x12Bit (331-7KB01) uses the parameters for the channel group 0/1 the parameters for further channel groups are ignored.
	Note! Parameters which are not supported by the Siemens hardware configurator may only be changed during run time by means of SFCs.
Install module	 Start the hardware configurator and load your project for the analog module. Open the hardware catalog to install the analog input module. In the hardware catalog the analog modules with the order-no.: 6ES7 331-7KB01 (2x12Bit) and 6ES7 331-7KF01 (8x12Bit) can be found at SIMATIC 300/SM-300/AI-300. Choose the according module and drag & drop this module to the concerning slot in the hardware configurator.
Parameterize the module	 Via double click on the wanted module in the hardware configurator you open the concerning parameter window. You can change the following module parameters: Starting address for CPU mapping Measuring ranges, measuring type and integration times for channel pairs Process interrupt at limit value overflow for channel 0 and channel 2 Limit value action at overflow Diagnosis and group diagnosis for each channel pair at wire break or measuring range over-/underflow.
Save and transfer your project	 Save and translate your project Switch your CPU in STOP Transfer your project into the CPU As soon as you switch the CPU into RUN, the parameters are transmitted to the analog input module. More information about the parameters can be found at the following pages.

Structure of the parameter bytes Record set 0, Record set 1

At the parameterization, a parameter area of 16byte length is stored in the record sets 0 and 1. Here the data irrelevant for the module AI 2x12Bit (331-7KB01) are ignored.

Using the SFCs 55, 56 and 57 you can only change parameters at record set 1 and transfer during runtime to the analog module. On this way parameters may be transferred which are not supported by the Siemens SIMATIC manager, as e.g. setting of high temperature measuring ranges.

Parameter
Record set 0
(not parameterizable
via SFC)

Record set 0 (Byte 0 to 1):

Byte	Bit 7 Bit 0	Default
0	Group diagnosis bit coded Bit 0: Channel 0/1 Bit 1: Channel 2/3 Bit 2: Channel 4/5 Bit 3: Channel 6/7 Bit 7 4: reserved	00h
1	Wire break test bit coded Bit 0: Channel 0/1 Bit 1: Channel 2/3 Bit 2: Channel 4/5 Bit 3: Channel 6/7 Bit 7 4: reserved	00h

Parameter

Record set 1 (parameterizable via SFC)

Record set 1 (Byte 0 to 13):

Byte	Bit 7 Bit 0	Default					
0	Bit 5 0: reserved Bit 6: Diagnostic interrupt release Bit 7: Process interrupt release						
1	Interference frequency suppression Bit 0, 1: Channel 0/1 00: 400Hz (2.5ms) Bit 2, 3: Channel 2/3 01: 60Hz (16.6ms) Bit 4, 5: Channel 4/5 10: 50Hz (20ms) Bit 6, 7: Channel 6/7 11: 10Hz (100ms)	AAh					
2	Mode Channel 0/1 7 4 3 0 Bit No. Bit 3 0: Measuring range 7 4 3 0 Bit-No. Bit 7 4: Measuring type Byte 29 Image: Compare 1 <	19h (+/-10V)					
3	Mode Channel 2/3 Coding for measuring type Bit 3 0: Measuring range Coding for measuring type Bit 7 4: Measuring type Coding for measuring type	19h (+/-10V)					
4	Mode Channel 4/5For the according coding of mea- suring range and measuring typeBit 3 0: Measuring range Bit 7 4: Measuring typeFor the according coding of mea- suring range and measuring type	19h (+/-10V)					
5	Mode Channel 6/7 Bit 3 0: Measuring range Bit 7 4: Measuring type	19h (+/-10V)					
6, 7	Upper limit value Channel 0	7FFFh					
8, 9	Lower limit value Channel 0	8000h					
10, 11	Upper limit value Channel 2	7FFFh					
12, 13	Lower limit value Channel 2	8000h					

1

Note for deactivating a channel group!

With the Coding 0000 0000 a channel group may be deactivated.

Modus per	The following section shows an overview of all measuring types and ranges
channel pair	plus binary coding for the parameterization.

Measuring range	Range / Repre	esentation		Range coding
+/- 80mV	94.071mV - 80_80mV	= End Overdrive region = Nominal range	(32511) (-27648 27648)	0001b
i, comv	- 94.074mV	= End Underdrive region	(-32512)	00010
	293.97mV	= End Overdrive region	(32511)	
+/- 250mV	- 250250mV	= Nominal range	(-2764827648)	0010b
	- 293.98mV	= End Underdrive region	(-32512)	<u> </u>
$+/_{-}500mV$	587.94111V		(32511) (27648 - 27648)	0011b
- JOOINV	- 587.96mV	= End Underdrive region	(-32512)	00110
	1.175V	= End Overdrive region	(32511)	
+/- 1V	- 11V	= Nominal range	(-2764827648)	0100b
	- 1.175V	= End Underdrive region	(-32512)	
	2.939V	= End Overdrive region	(32511)	
+/- 2.5V	- 2.52.5V	= Nominal range	(-2764827648)	0101b
	- 2.933V	= End Underdrive region	(-32512)	
/	5.879V	= End Overdrive region	(32511)	
+/- 5V	- 55V	= Nominal range	(-2764827648)	0110b
	- 5.879V	= End Underdrive region	(-32512)	
	11.758V	= End Overdrive region	(32511)	40041
+/- 10V	- 1010V	= Nominal range	(-2764827648)	1001b
	- 11.759V	= End Underdrive region	(-32512)	-
	5.703V	= End Overdrive region	(32511)	01111
1 5V	15V	= Nominal range	(027648)	01110
	0.2967	= End Underdrive region	(- 4864)	

	Measuring type	Voltage	measuring	(Measuring	type	coding:	0001b)
--	----------------	---------	-----------	------------	------	---------	--------

Measuring type 4wire Current measuring (Measuring type coding: 0010b)

Measuring range	Range / Repre	esentation		Range coding
+/- 3.2mA	3.762mA - 3.23.2mA - 3.762mA	 End Overdrive region Nominal range End Underdrive region 	(32511) (-2764827648) (-32512)	0000b
+/- 10mA	11.758mA - 1010mA - 11.758mA	 End Overdrive region Nominal range End Underdrive region 	(32511) (-2764827648) (-32512)	0001b
+/- 20mA	23.515mA - 2020mA - 23.515mA	 End Overdrive region Nominal range End Underdrive region 	(32511) (-2764827648) (-32512)	0100b
0 20mA	23.515mA 020mA - 3.518mA	 End Overdrive region Nominal range End Underdrive region 	(32511) (027648) (-4864)	0010b
4 20mA	22.810mA 420mA 1.185mA	End Overdrive regionNominal rangeEnd Underdrive region	(32511) (027648) (-4864)	0011b

Measuring type 2wire Current measuring (Measuring type coding: 0011b)

Measuring range	Range / Repr	resentation		Range coding
4 20mA	22.810mA 420mA 1.185mA	 End Overdrive region Nominal range End Underdrive region 	(32511) (027648) (-4864)	0011b

Measuring range	Range / Representation		Range coding
150 Ohm	176.383 Ohm = End Overdrive region 0150 Ohm = Nominal range negative values physically not possible	(32511) (027648)	0010b
300 Ohm	352.767 Ohm = End Overdrive region 0300 Ohm = Nominal range negative values physically not possible	(32511) (027648)	0100b
600 Ohm	705.534 Ohm = End Overdrive region 0600 Ohm = Nominal range negative values physically not possible	(32511) (027648)	0110b

Measuring type 4wire Resistance measuring (Measuring type coding: 0100b)

Measuring type 4wire Thermo resistance (Measuring type coding: 1000b)

Measuring range	Range / Representation			Range coding
Pt100 Standard	1000°C - 200850°C - 243°C (0.1°C/digit)	End Overdrive regionNominal rangeEnd Underdrive region	(10000) (-20008500) (-2430)	0010b
Pt100 Climate	155°C - 120130°C - 145°C (0.01°C/digit)	= End Overdrive region= Nominal range= End Underdrive region	(15500) (-1200013000) (-14500)	0000b
Pt 100 reference junction	1000 -100200 -243 (0.1°C/Digit)	End Overdrive regionNominal rangeEnd Underdrive region	(10000) (-10002000) (-2430)	1101b ²⁾
Ni100 Standard	295°C - 60250°C - 105°C (0.1°C/digit)	End Overdrive regionNominal rangeEnd Underdrive region	(2950) (-6002500) (-1050)	0011b ¹⁾
Ni100 Climate	295°C - 60250°C - 105°C (0.01°C/digit)	= End Overdrive region= Nominal range= End Underdrive region	(29500) (-600025000) (-10500)	0001b

¹⁾ Please use up to the firmware version V.1.2.6 of the analog module the coding 1011b. The current firmware version may be found at the front flap beneath the label strip.

²⁾ The measuring range Pt100 reference junction is available starting with firmware version V. 1.3.8. Since this measuring range is not supported by the Siemens SIMATIC manager, the parameterization only takes place exclusively at run time.

Measuring type Thermocouple:

compensation external,	linear	(Measuring	type coding:	1110b)
compensation internal,	linear ((Measuring	type coding: *	1101b)

Measuring range	Range / Repre	esentation in °C (0.1°C/digit)		Range coding
Type J [Fe-Cu-Ni IEC]	1450°C -2101200°C -210°C	 End Overdrive region Nominal range End Underdrive region 	(14500) (-2100 12000) (-2100)	0101b
Type K [Ni-Cr-Ni]	1622°C -270 1372°C -270°C	 = End Overdrive region = Nominal range = End Underdrive region 	(16220) (-2700 13720) (-2700)	1000b
Type N [Ni-Cr-Si]	1550°C -2701300°C -270°C	End Overdrive regionNominal rangeEnd Underdrive region	(15500) (-270013000) (-2700)	0001b
Type E [Ni-Cr - Cu-Ni]	1200°C -2701000°C -270°C	End Overdrive regionNominal rangeEnd Underdrive region	(12000) (-270010000) (-2700)	0010b
Type L [Fe-Cu-Ni]	1150°C -200900°C -200°C	 End Overdrive region Nominal range End Underdrive region 	(11500) (-20009000) (-2000)	0110b
Type T [Cu-Cu-Ni]	540 -270400 -270	 End Overdrive region Nominal range End Underdrive region 	(5400) (-27004000) (-2700)	0111b ¹⁾
Type R [PtRh-Pt]	2019 -501769 -170	= End Overdrive region= Nominal range= End Underdrive region	(20190) (-50017690) (-1700)	0011b ¹⁾
Type S [PtRh-Pt]	2019 -501769 -170	End Overdrive regionNominal rangeEnd Underdrive region	(20190) (-50017690) (-1700)	0100b ¹⁾
Type B [PtRh-PtRh]	2070 01820 -120	End Overdrive regionNominal rangeEnd Underdrive region	(20700) (018200) (-1200)	0000b ¹⁾
Type C [WRe5-WRe26]	2500 02315 -120	= End Overdrive region = Nominal range = End Underdrive region	(25000) (023150) (-1200)	1010b ¹⁾

Measuring type Thermocouple:

compensation external (**Measuring type coding: 1011b**) compensation internal (**Measuring type coding: 1010b**)

The evaluated thermo electromotive force is added to the force of the internal or external reference junction and is mapped to the 80mV measuring range.

Measuring range	Range / Repr	Range coding		
Type J [Fe-Cu-Ni IEC]				0101b
Type K [Ni-Cr-Ni]				1000b
 and so on (see above)	94.071mV - 8080mV - 94.074mV	End Overdrive regionNominal rangeEnd Underdrive region	(32511) (-2764827648) (-32512)	
Type C [WRe5-WRe26]				1010b ¹⁾

¹⁾ The measuring range is available starting with firmware version V. 1.3.8. Since this measuring range is not supported by the Siemens SIMATIC manager, the parameterization only takes place exclusively at run time.

331-7Kx01 - AI 8(2)x12Bit - Diagnostics

Diagnostics As soon as an error occurs, like "wire break" or "measuring value out of range", an entry is made in the diagnostic area that can be evaluated by means of the user application.

If you have released the diagnostic interrupts at the parameterization, incoming and outgoing error events are signaled by interrupts and monitored on the according analog input module via LED.

At a diagnostic interrupt the CPU interrupts the user application and works off the OB 82. For more detailed diagnostic information you may call the SFC 51 res. SFC 59 in the OB 82. The diagnostic data is consistent until you leave the OB 82.

Starting the
diagnosisWhen an error occurs and after error correction, the diagnosis is started.
Via the parameterization you fix the diagnosis behavior at error:

perties - Al8x12Bit - (R0/S	4)			
ieneral Addresses Inputs				
Enable				
Diagnostic Interrupt	Hardware Interru	upt When Limit B	xceeded	
Inpu	0.1	2-3	4 - 5	6-7
Djagnostics				
Group Diagnostics:				
with Check for Wire Break:			Г	
Measuring				
Measuring Type:	4DMU	4DMU	E	E
Measuring Range:	420 mA	420 mA	+/-10 V	+/-10 V
Position of Measuring Range Selection Module:	[C]	[C]	[B]	[B]
interference frequency	50 Hz	50 Hz	50 Hz	50 Hz
Trigger for Hardware Interrupt	Channel 0	Channel 2		
High Limit:				
Low Limit:				
OK			Car	ncel Help

A diagnostic interrupt is only transmitted to the CPU, if you activate the diagnostic interrupt in the parameterization window.

The following errors may initialize a diagnosis:

- Error in project engineering res. parameterization
- Wire break at current measuring
- Measuring range overflow
- Measuring range underflow
- Common mode error
- Lost process interrupt
- Failure of the external voltage supply

Error indication via measuring value and LEDs Every analog input module sends, independent from the parameterization, the measuring value 7FFFh at overflow and 8000h at underflow when recognizing an error.

At activated *group diagnosis* the group diagnosis-LED (SF) and the error-LED that is assigned to that channel are blinking.

If you additionally activated the *wire break diagnosis* at current measuring, a wire break is shown via the error LED assigned to this channel.

Evaluating the diagnosis At a diagnosis event the CPU interrupts the user program and branches into OB 82. This OB allows you via according programming to request detailed diagnostic information by means of the SFCs 51 and 59 and react to it.

After processing of the OB 82, the processing of the user application is continued. The diagnostic data are consistent until leaving the OB 82.

As soon as you have activated the diagnostic interrupt release, *record set 0* is transferred to the superordinated system in cause of an error. The *record set 0* has a fixed content and a length of 4byte. The content of *record set 0* may be monitored in plain text in the diagnosis window of the CPU.

For the extended diagnosis during run time, you may also evaluate the *record set 1* of 16byte length via SFCs 51 and 59.

Record set 0 and 1 have the following structure:

Byte	Bit 7 Bit 0	Default
0	Bit 0: Error in module	00h
	Bit 1: reserved	
	Bit 2: External error	
	Bit 3: Channel error	
	Bit 4: external voltage supply missing	
	Bit 6, 5: reserved	
	Bit 7: Wrong parameters in module	
1	Bit 3 0: Module class	15h
	0101 Analog module	
	Bit 4: Channel information present	
	Bit 7 5: reserved	
2	reserved	00h
3	Bit 5 0: reserved	00h
	Bit 6: Process interrupt lost	
	Bit 7: reserved	

Record set 0 (Byte 0 to 3):

Diagnosis

record set 0

Diagnostics record set 1

Byte 0 to 15:

The record set 1 contains the 4byte of record set 0 and additionally 12byte module specific diagnostic data.

The diagnostic bytes have the following assignment:

Record set 1 (Byte 0 to 15).

Byte	Bit 7 Bit 0	Default
0 3	Content record set 0 (see page before)	-
4	Bit 6 0: Channel type	71h
	70h: Digital input	
	71h: Analog input	
	72h: Digital output	
	73h: Analog output	
	74h: Analog in-/output	
	Bit 7: More channel types present	
	0: no	
	1: yes	
5	Bit 7 0: Number of diagnostic bits, that the module throws per channel	08h
6	Bit 7 0: Number of similar channels of a module	04h
7	Bit 0: Channel error Channel 0	00h
	Bit 7: Channel error Channel 7	
8	Bit 0: Project engineering/Parameterization error Channel 0	00h
	Bit 1: Common mode error	
	Bit 3 2: reserved	
	Bit 4: Wire break Channel 0	
	Bit 5: reserved	
	Bit 6: Underflow Channel 0	
	Bit 7: Overflow Channel 0	
15	Bit 0: Project engineering/Parameterization error Channel 7	00h
	Bit 1: Common mode error	
	Bit 3 2: reserved	
	Bit 4: Wire break Channel 7	
	Bit 5: reserved	
	Bit 6: Underflow Channel 7	
	Bit 7: Overflow Channel 7	



Note!

Please note that the AI 2x12Bit (331-7KB01) exclusively supplies diagnostic data of the channel group 0/1!

Error cause and remedy

Message	Possible error cause	Remedial
Project engineering/	Parameterization at run time:	Proof the parameteri- zation during run time
Parameterization error	Wrong function code in record set	
Wire break	Sensor allocation is too high-impedance	install another sensor type or cable with a higher cross-section
	Interruption of the conductor between module and sensor	Install conductor connection
	Channel is not wired (open)	Deactivate the channel group (parameter measuring type)
		Wire the channel
Measuring range underflow	Input value is under the underdrive region, error causes may be:	
	 at measuring range 4 20mA, 1 5V 	
	 sensor connection polarity inversion 	Check connections
	- wrong measuring range	Parameterize another measuring range
	 other measuring ranges 	Parameterize another
	- wrong measuring range	measuring range
Measuring range overflow	Input value higher than overdrive region	Parameterize another measuring range
Process interrupt lost	During the processing of a process interrupt in OB40, a new process interrupt with the same error cause occurs.	
Failure of the external power supply	Connection of the external power supply forgotten	Supply the module with external DC 24V
	Power supply failure	Control external power supply and change it
	Cable defect res. not correctly connected	Control cable res. replace it
Common mode	Different potentials between grounds >3V or wire break at ground	Remove wire break, lower potential difference

Process interrupts Process interrupts are limit value interrupts. They occur if they are released via parameterization and a measuring value is outside the defined range. Process interrupts may only parameterized for the channels 0 and 2.

When a process interrupt occurs, the CPU interrupts the user application and processes the OB 40.

With the help of the OB 40 you may define, how your CPU should react at a process interrupt.

Initializing the process interrupt As soon as a measuring value is out of the range defined in the parameterization, a processes interrupt is initialized, if this option is released.

> Via the parameterization you define the part of the nominal range, in which the value has to be, by means of defining high and low limit.

> A process interrupt may only be initialized, when you have activated *hardware interrupt when limit exceeded.*

perties - Al8x12Bit - (R0/S	4)				
eneral Addresses Inputs					
Enable					
Diagnostic Interrupt	Hardware Interru	upt When Limit E	xceeded		
Input	0-1	2-3	4 - 5	6-7	
Djagnostics					
Group Diagnostics:					
with Check for Wire Break:			Г	Г	
Measuring					
Measuring Type:	4DMU	4DMU	E	E	
Measuring Range:	420 mA	420 mA	+/-10 V	+/- 10 V	
Position of Measuring Range Selection Module:	[C]	[C]	[B]	[B]	
interference frequency	50 Hz	50 Hz	50 Hz	50 Hz	
Trigger for Hardware Interrupt	Channel 0	Channel 2			
High Limit:	8.000 mA	mA			
Low Limit: 🦯	4.000 mA	mA			
 ОК			Ca	ncel He	elp

You may activate a process interrupt for channel 0 and 2.

Using the default configuration, the process interrupts are not activated.

Reaction to a the
process interruptAt a process interrupt the CPU interrupts the user application and branches
into the OB 40.More detailed information about the channel, which limit value has been

exceeded, are stored in the OB 40 in the variable OB 40_POINT_ADR in the local data double word 8 (LD 8).

The LD 8 has the following structure:

Byte	Bit 7 Bit 0
0	Bit:0 = 1: Upper limit value of channel 0 has been exceeded
	Bit:1 = 1: Upper limit value of channel 2 has been exceeded
1	Bit:0 = 1: Lower limit value of channel 0 has been exceeded
	Bit:1 = 1: Lower limit value of channel 2 has been exceeded
2 3	reserved

Diagnostic message
"Process interrupt
lost"If a second identical process interrupt occurs during processing interrupt in
OB 40, the CPU branches into the OB 82 and activates the bit 6 in record
set 0 of byte 3 for "process interrupt lost".

After having processed the OB 82, the CPU jumps back to OB 40.

Influence of the measuring values The behavior of the analog input module depends on the location of the measuring value inside the value range.

The following table lists the different behaviors:

Measuring value is in	transmitted	SF-LED ⁴⁾	Diagnostics	Interrupt
Nominal range	meas. value	_	-	-
Over-/Underdrive region	meas. value		-	-
Overflow	7FFFh	ON ³⁾	Entry is set 3)	Diag. interrupt ¹⁾
Underflow	8000h	ON ³⁾	Entry is set 3)	Diag. interrupt ¹⁾
outside the parameterized limit value	meas. value	-	-	Process interrupt ²⁾

¹⁾ only if diagnostic interrupt is released in the parameterization.

²⁾ only if process interrupt is released in the parameterization.

³⁾ only if group diagnostics is released in the parameterization.

⁴⁾ independently from the chosen diagnostics, the group error LED is on when the external power supply is missing.

331-7Kx01 - AI 8(2)x12Bit - Technical Data

Module name	VIPA 331-7KF01	VIPA 331-7KB01	
Dimensions and Weight			
Dimensions (WxHxD in mm)	40x125x120		
Weight	ca. 2	200g	
Data for specific module			
Number of inputs	8	2	
 for 4wire resistance-type sensor 	4	1	
Length of cable			
- shielded	200m / 50m at meas	suring range ±80mV	
Programming specifications	331-7KF01	331-7KB01	
Input data	8word	2word	
Parameter data	16byte	16byte	
Diagnostic data	16byte	16byte	
Voltages, Currents, Potentials			
Rated supply voltage of electronics L+	DC	24V	
 Reverse polarity protection 	ye	es	
Power supply of the transmitters			
- Supply voltage	13V at 30mA		
- Supply current	max. 30mA (per channel)		
- Short-circuit-proof	yes		
Constant current for resistance-type sensor	2.25	imA	
Isolation			
 between channels and backplane bus 	ye	es	
 between channels and power supply of the electronics 	yes (not with 2wire measuring transducer		
Permitted potential difference			
- between the inputs (U_{CM})	DC	3V	
- between M_{ANA} and M_{INTERN} (U _{ISO})	DC 75V /	/ AC 60V	
- between the inputs and M_{ANA} (U_{CM})	DC 3V (at Signal = 0V)		
Insulation tested with	DC 5	500V	
Current consumption			
- from the backplane bus	max.	95mA	
- from the power supply L+	max. 100mA (witho transc	ut 2wire measuring lucer)	
Power dissipation of the module	3.0	W	

Analog value generation	VI	PA 33	1-7KF	01	VI	PA 33 ⁻	1-7KE	801
Measuring principle	Sigma delta							
Integration time/conversion time/resolution (per channel)								
- programmable				ye	es			
- Conversion rate in Hz	400	60	50	10	400	60	50	10
- Integration time in ms	2.5	16²/ ₃	20	100	2.5	16²/ ₃	20	100
- Basic conversion time in ms	4	18	22	68	4	18	22	68
Additional conversion time for open circuit monitoring in ms				4r	ns			
- Resolution (incl. overrange) in Bit	9	12	12	14	9	12	12	14
- Noise suppression for frequency f1 in Hz	-	-	-	50/ 60	-	-	-	50/ 60
- Basic execution time of the module in ms (all channels enabled)	42	154	186	554	18	46	54	146
Smoothing of the measured values				no	ne			
Suppression of interference, limits error								
Noises suppression for f=n x (f1 ±1%) (f1=interferer	nce fre	equen	cy, n=	1,2,)			
- Common-mode interference ($U_{CM} < 3V$)				> 7(0dB			
 Series-mode noise (peak value of noise < nominal value of input range 				> 4(0dB			
Crosstalk between the inputs				> 5	0dB			
Operational limit (in the entire temperature range, v	vith re	ferenc	e to t	he inp	ut ran	ge)		
		Me	easurii	ng ran	ige		Tole	rance
- Voltage input			±80)mV			±1.	0%
		±250r	nV, ±:	500m\	/, ±1V	, ,	±0.	6%
Current input	±	2.5V,	±5V,:	±10V,	15	o∨ ∧	±0.	8%
	-	±3.2m	$A, \pm 10$	JMA, ∃ ⊿	EZUM/	4	±0.	7%
Posistero		02	20MA,	.4∡ 2000	20MA		±0.	7%
- Resistors		D+100	00 <u>1</u> 2, .	300 <u>0</u> 2, dard	10002	2	±0.	7 70
			100 i	uaru, Climat	ים מי		±0. +0	8%
- Thermocouple		Tvr	ne.lk	(N F	.C =		+1	3%
			Tvr.	ч, н, <u>-</u> ре Т	-, -		+2	0%
		e S. B.	C. R	•				
	(see	note a	t the	end of	f the t	able)		
Basic error (operational limit at 25°C referred to the	input	range)					
		Me	easurii	ng ran	ige		Tole	rance
- Voltage input			±80)mV			±0.	7%
		±250r	nV, ±8	500m\	/, ±1∨	/	±0.	4%
	±	2.5V,	±5V, :	±10V,	1 5	δV	±0.	6%
- Current input	=	±3.2m	A, ±10)mA, ±	±20m/	4	±0.	5%
		0 2	20mA,	4 2	20mA		±0.	5%
- Resistors		0 1	50Ω, 3	300Ω,	600Ω	2	±0.	5%

Suppression of interference, limits error	VIPA 331-7KF01	VIPA 331-7KB01
- Resistance thermometer	Pt100 Standard, I	Ni100 ±0.5%
	Pt100 Climat	e ±0.6%
- Thermocouple	Type J, K, N, L	., E ±0.7%
	Туре Т	±1.1%
	Type S, B, C, R	
	(see note at the end of	the table)
Temperature error (with reference to the input range)	±0.00	5%/K
Linearity error (with reference to the input range)	±0.0)2%
Repeatability (in steady state at 25°C, with reference to the input range)	±0.0)5%
Temperature error of internal compensation	±1.	5%
Status, Interrupts, Diagnostics		
Interrupts	parameterizable	parameterizable
	(Channel 0 and 2)	(Channel 0)
- Process interrupt when limit has been	parameterizable	parameterizable
- Diagnostic interrupt	parameterizable	
- Group error display	red I F	
	red ED (E0 E7) red ED (E0	
- Diagnostics information read-out	possible	
Data for selecting a sensor		
	Input range	Input resistance
- Voltage	± 80mV, ± 250mV	10MΩ
, v	± 500mV, ± 1V	10MΩ
	± 2.5V, ± 5V	100kΩ
	1 5V, ± 10V	100kΩ
- Current	± 3.2mA, ± 10mA, ± 20mA	85Ω
	0 20mA, 4 20mA	85Ω
- Resistors	0150Ω, 300Ω, 600Ω	2 10MΩ
- Resistance thermometer	Pt100, NI100	10MΩ
- Thermocouples	Type J, K, N, L, E, T, S, B, C, R	10MΩ
Maximum input voltage for voltage input (destruction limit)	max. 20V	
Maximum input current for current input L+ (destruction limit)	max. 40mA	

Data for selecting a sensor	VIPA 331-7KF01 VIPA 331-7		
Connection of the sensors			
- for measuring voltage	possible		
- for measuring current			
as 2wire transmitter	possi	ble	
as 4wire transmitter	possi	ble	
- for measuring resistance			
with 2conductor connection	possi	ble	
with 3conductor connection	possible		
with 4 conductor connection	possible		
Characteristic linearization			
- for RTD	Pt100, NI 100 Standard / Climate		
- for thermocouples	Type E, N, J, K, L	., T, S, B, C, R	
	Ni100 Standar	rd / Climate	
Temperature compensation	parameterizable		
 internal temperature compensation 	ure compensation possible		
 external temperature compensation with compensating box 	possi	ble	
 Compensation for 0°C comparison point temperature 	possi	ble	
Technical unit for temperature measurement	C°		

Thermocouple for high temperature measurement

The thermocouples for high temperature measurement (Type S, B, C, R) produce physically caused smaller thermo electromotive forces than the "normal" thermocouples (Type E, N, J, K, L).

In the following table there is a comparison between the thermo electromotive forces of the thermocouple of the type N to type S, B, C, R.

Thermo electromotive	0°C	500°C	1000°C	1700°C
forces of Thermocouples				
Type N in μV / °C	26	38	39	not possible
Type S in μV / °C	5	10	12	12
Type B in μV / °C	0	5	9	11
Type C in μV / °C	13	19	18	14
Type R in μV / °C	5	11	13	13

Chapter 7 Analog Output Modules

Outline This chapter contains a description of the structure and the operation of the VIPA analog output modules.

System overview

Analog output modules SM 332 In the following you will get an overview over the analog output modules that are available at VIPA:



Order data	Туре	Order number	Page
analog output	AO 2x12Bit, U/I	VIPA 332-5HB01	7-13
modules	AO 4x12Bit, U/I	VIPA 332-5HD01	7-13
	AO 4x12Bit, I for manual operation	VIPA 332-5HD50	7-18
	AO 4x12Bit. U for manual operation	VIPA 332-5HD60	7-18

Security hint



Attention!

Please regard that the modules VIPA 332-5Hx01 do not have hardware precautions against wrong parameterization. The setting of the according measuring range is exclusively at the project engineering. At the project engineering you should be very careful.

With the modules VIPA 332-5HDx0 you can cause a jump in the analog value by means of the switch, independently of the mode of operation of the CPU, as long as the module is power supplied. This could lead to material damage or personal injury!

Please regard also that disconnecting res. connecting during operation, the so-called "Hot Swapping", is not possible!

General	
Cables for analog signals	For analog signals you should use isolated cables to reduce interference. The cable screening should be grounded at both ends. If there are differences in the potential between the cable ends, there may occur a potential compensating current that could disturb the analog signals. In this case you should ground the cable screening only at one end.
Connecting loads and actuators	 Depending on the module the following actuators may be connected: Current input: ±20mA, 4 20mA, 0 20mA Voltage input: ±10V, 1 5V, 0 10V
	Note! Please take always care of the correct polarity when connecting actuators! Please leave the output pins of not used channels disconnected and configure the <i>output type</i> of the channel to "deactivated".
Parameterization	The modules can be configured by means of a hardware configuration or rather during run time by SFCs. In not parameterized status, the modules with order number 332-5Hx01 are set to voltage output "±10V". The interrupt output of every module is deactivated.
Diagnostic functions	 Every module described here has diagnostic functions. Depending on the module the following errors may initialize a diagnostic message: A diagnostic interrupt is only transmitted to the CPU, if you have activated the diagnostic interrupt in the parameterization window. The following errors a diagnosis: Wire break at current output (only 332-5Hx01) Ground short circuit (only 332-5Hx01) Operate the front switch (only 332-5HDx0) Failure of the external voltage supply Project engineering and parameterization error For more detailed diagnostic information you may call the SFCs 51 and 59 during run time. You can request detailed diagnostic information and react on it by means of the SFCs.
Output pulse at Power ON/OFF and at output range alterations during run time	System-dependently at switching on/off the power supply and at output range alterations during run time, there may arise wrong values for app. 10ms.

Connecting loads and actuators

Connecting loads at current output

Loads at the current output have to be connected at Q_X and associated ground M_X of the analog circuit. Please always pay attention to correct polarity.



Connecting loads at voltage output at 4-wire cabling (only 332-5Hx01)

The connection of a load at a voltage output can take place both in 2- and in 4-wire cabling. Please note with the modules 332-5HDx0 the 4-wire cabling is not possible.

With 4-wire cabling you achieve a high exactness at the load. The sensor lines $S+_X$ and $S-_X$ are directly connected to the load. Thus, the voltage may be measured and adjusted directly at the load.

Interference or voltage losses may cause potential differences between S_{-x} and M_x . These should not exceed the permissible value of DC 3V, because this may disturb the accuracy of the analog signal.



Connecting loads at voltage output at 2-wire cabling

Connect the load at pin QV_X and the point of reference of the measuring circle M_X (x = No. of the channel).


Analog value representation

Analog valueThe analog values are only processed by the CPU in binary representation.representationHereby the process signals are transformed into digital format in the analog
module and passed on to the CPU as word variable.

The digitized analog value is the same for input and output values at the same nominal range.

		Analog value														
				High	byte							Low	byte			
Bit number	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Resolution	SG		Analog value (word)													
12bit + Sign	SG	Rele	Relevant output value X X X					Х								
11bit + Sign	SG	Rele	vant	outpu	t valu	ie							Х	Х	Х	Х
10bit + Sign	SG	Rele	vant	outpu	t valu	le						Х	Х	Х	Х	Х

The resolution depends on the used module as follows:

* The least significant irrelevant bits of the output value are marked by "X".

Sign bit (SG)The algebraic sign bit is represented by Bit 15. Here it is essential:
Bit 15 = "0" \rightarrow positive value
Bit 15 = "1" \rightarrow negative value

Parameterization - Basics

Overview	There are the following possibilities for parameterization:				
	 Parameterization by hardware configuration of Siemens SIMATIC manager or with WinPLC7 from VIPA. 				
	 Parameterization during run time by means of SFCs. 				
Parameterization by hardware configuration	 To be compatible to the Siemens SIMATIC manager the following steps are to be accomplished: Start the hardware configurator from Siemens Create a new project Configure your CPU. Link-up your System 300V modules in the plugged-in sequence starting with slot 4. Here the analog output modules of VIPA are to be projected as analog output modules of Siemens in accordance with the following rules: 				
	VIPA 332-5HD01 to be configured as 6ES7 332-5HD01-0AB0 VIPA 332-5HDx0				
	VIPA 332-5HB01 to be configured as 6ES7 332-5HB01-0AB0				
	The analog output modules can be found at the hardware catalog at Simatic $300 > SM-300$.				
	• If needed parameterize the CPU respectively the modules. The parameter window appears as soon as you double click on the according module. At this window the according parameter can be changed.				
	 Save your project, switch the CPU to STOP and transfer your project to the CPU. As soon as the CPU is switched to RUN the parameters are transferred to the connected modules. 				
Parameters	The following parameters can be adjusted at the analog output modules:				
	 Starting address of the output data 				
	Output type and behavior				
	Reaction at CPU-STOP				
	Diagnostics and interrupt reaction				
	A closer description of the parameters can be found at the following pages.				

Parameterization during run time by means of SFCs

If the module gets parameters, which are not supported by the module, for example a current module is to be configured as a voltage module, these parameters are interpreted as wrong parameters and an error is initialized.

At the parameterization, 16byte long parameter area is set in the record sets 0 and 1. Deploying the SFCs 55, 56 and 57, you may alter parameters during run time and transfer them to the module. The following tables show the structure of the parameters in record set 0 and 1:

Parameters

Record set 0 (not parameterizable via SFC)

Record set 0 (Byte 0 to 1):

Byte	Bit 7 Bit 0	Default
0	Sum diagnosis bit coded	00h
	Bit 0: Channel 0	
	Bit 1: Channel 1	
	Bit 2: Channel 2	
	Bit 3: Channel 3	
	Bit 7 4: reserved	
1	reserved	00h

Parameters

Record se	et 1 Record set 1 (Byte 0 to 13):	Default			
Byte	Bit 7 Bit 0	332-5Hx01	332-5HD50	332-5HD60	
0	Bit 5 0: reserved Bit 6: Diagnostic interrupt release Bit 7: reserved	00h	00h	00h	
1	Reaction at CPU-STOP Bit 0: Channel 0 Bit 1: Channel 1 Bit 2: Channel 2 Bit 3: Channel 3	00h	00h	00h	
2	Mode Channel 0 Bit 3 0: Output range Bit 7 4: Output type The according	19h (+/-10V)	23h (420mA)	18h (010V)	
3	Mode Channel 1 coding of Bit 3 0: Output range output type Bit 4 7: Output type and output	19h (+/-10V)	23h (420mA)	18h (010V)	
4	Mode Channel 2range can beBit 3 0: Output rangefound at theBit 7 4: Output typefollowing page!	19h (+/-10V)	23h (420mA)	18h (010V)	
5	Mode Channel 3 Bit 3 0: Output range Bit 7 4: Output type	19h (+/-10V)	23h (420mA)	18h (010V)	
6, 7	Replacement value Channel 0	0000h	0000h	0000h	
8, 9	Replacement value Channel 1	0000h	0000h	0000h	
10, 11	Replacement value Channel 2	0000h	0000h	0000h	
12, 13	Replacement value Channel 3	0000h	0000h	0000h	



Note!

With setting the mode parameter to 00h the according channel is deactivated. To switch at not symmetric output range the current respectively the voltage output to 0 value at CPU STOP, the following replacement values should be used:

output range 15V:	0V	\leftrightarrow	-6912dez = E500h
output range 420mA:	0mA	\leftrightarrow	-6912dez = E500h

Release diagnostic Please regard as soon as you release the diagnostic interrupt at run time, the according group diagnostics are just activated during hardware configuration. Otherwise no interrupt can be initialized.

More information can be found at "Diagnostics" further down.

CPU-Stop reaction Here the module reaction at CPU-STOP can be set. You have the following possibilities:

- 0CV: output de-energized (according to the module)
- KLV: Keep last value
- SV: Substitute a value

Get mode Depending on the module at the register "Outputs" at *Output* the type voltage, current output or deactivated and the according range can be selected.

As shown in the following illustration the parameter *mode* is made up of the coding of the output range and type during run time parameterization each channel.



The corresponding codes can be found in the following table. Within the output types the output ranges are specified, for which a binary output range code is to be specified in each case.

Output range	Range / Unit	Output range coding
010V	11.758V= End overdrive region (32511) 010V = Nominal region (027648)	1000b
15V	5.879V = End overdrive region (32511) 15V = Nominal range (027648) 0V = End underdrive region (-6912)	0111b
+/- 10V	11.758V = End overdrive region (32511) -1010V = Nominal range (-2764827648) -11.759V = End underdrive region (-32512)	1001b

Output type current output (Output type coding: 0010b)

Output range	Range / Unit	Output range coding
020mA	23.515mA = End overdrive region (32511) 020mA = Nominal range (027648)	0010b
420mA	22.810mA = End overdrive region (32511) 420mA = Nominal range (027648) 0mA = End underdrive region (-6912)	0011b
+/- 20mA	23.515mA = End overdrive region (32511) -2020mA = Nominal range (-2764827648) -23.515mA = End underdrive region (-32512)	0100b

Diagnostics

OutlineAs soon as an error occurs and activated Group diagnostics, it is
protocolled in the diagnostic area that can be evaluated by means of the
user application.If the diagnostic interrupt is released at the parameterization, incoming and
outgoing error events are signaled by interrupts and monitored on the
according analog output module via LED.At a diagnostic interrupt the CPU interrupts its user application and works
on the OB 82. For more detailed diagnostic information you may call the
SFC 51 res. SFC 59 in the OB 82. The diagnostic data is consistent until
you leave the OB 82.

Starting the
diagnosisWhen an error occurs and after error correction, the diagnosis is started.
Via the parameterization you fix the diagnosis behavior at error:

	0	1	2	3
<u>D</u> iagnostics Group Diagnostics:				
Output				
Type of Output:	E		E	
Output Range:	+/- 10 V	420 mA	+/- 10 V	···
Reaction to CPU-STOP:	OCV	OCV	OCV	
Substitute Value:				

A diagnostic interrupt is only transmitted to the CPU, if you have activated the diagnostic interrupt in the parameterization window.

The following errors a diagnosis:

- Wire break at current output (only 332-5Hx01)
- Ground short circuit (only 332-5Hx01)
- Operate the front switch (only 332-5HDx0)
- Failure of the external voltage supply
- Project engineering and parameterization error

Diagnostics data The diagnostics data is stored in the record sets 0 and 1 of the system data area.

As soon as you have activated the diagnostic interrupt release of the parameter area (record set 1, byte 0), on error *record set 0* of the diagnostics data is transferred to the superordinated system.

For extended diagnosis during run time, you may also evaluate the *Record* set 1 via the SFCs 51 and 59.

Evaluate
diagnosisAt a diagnostics event the CPU interrupts the user program and branches
into OB 82. This OB allows you via according programming to request
detailed diagnostic information by means of the SFCs 51 and 59 and react
to it.

After the working off of the OB 82, the processing of the user application is continued. The diagnostic data are consistent until leaving the OB 82.

DiagnosisThe record set 0 has a fixed content. The content of record set 0 may beRecord set 0monitored in plain text in the diagnosis window of the CPU.

Byte	Bit 7 Bit 0	Default
0	Bit 0: Error in module	00h
	Bit 1: reserved	
	Bit 2: External error	
	Bit 3: Channel error	
	Bit 4: external voltage supply missing	
	Bit 5, 6: reserved	
	Bit 7: Wrong parameter in module	
1	Bit 3 0: Module class	15h
	0101 Analog module	
	Bit 4: Channel information present	
2	Bit 0, 1 reserved	00h
	Bit 2: Operating status 0: RUN	
	1: STOP	
	Bit 7 4: reserved	
3	not used	00h

DiagnosisThe record set 1 contains the 4byte of record set 0 and additionally 8byteRecord set 1module specific diagnostic data.The diagnostic bytes have the following content:

The diagnostic bytes have the following content:

Byte	Bit 7 Bit 0		Default		
0 3	Content record set 0 (see page before	9)			
4	Bit 60: Channel type:		73h		
	73h: Analog output				
	Bit 7: More channel types present				
	0: no				
	1: yes				
5	Bit 7 0: Number of diagnostic bits, that the module throws per channel				
6	Bit 7 0: Number of similar channels of a module				
7	Bit 0: Channel error Channel 0		00h		
	Bit 1: Channel error Channel 1				
	Bit 2: Channel error Channel 2				
	Bit 3: Channel error Channel 3				
	Bit 4: Channel error Channel 4				
	Bit 7 5: reserved				
	332-5Hx01	332-5HDx0			
8	Channel specific error: Channel 0 Bit 0: Project engineering/ Parameterization error Bit 1, 2: reserved Bit 3: Short circuit after M Bit 4: Wire break Bit 75: reserved	Channel specific error: Channel 0 Bit 0: Project engineering/ Parameterization error Bit 41: reserved Bit 5: Front switch 0: Automatic 1: Hand operation	00h		
0	Channel anagifia arrar: Channel 1	Bil 70. Teserved	00h		
9	Content see Channel 0	Content see Channel 0	0011		
11	Channel specific error: Channel 3	Channel specific error: Channel 3	00h		
	Content see Channel 0	Content see Channel 0			
12 15	reserved				

Channel error by switching to manual operation at 332-5HDx0 The switch to *manual operation* is interpreted as a channel error. The appropriate bit for channel errors in byte 7 of record set 1 is set.

An Interrupt_{going} is only possible if all by group diagnostics activated switches are turned to automatic operation.

Error indication
via LEDs
(only 332-5Hx01)At activated group diagnostics the group error LED (SF) and the according
channel error LED are activated by diagnostic requirement of the modules
with order no. 332-5Hx01.

Evaluating the
diagnosisAt a diagnostic requirement the CPU interrupts the user program and
branches into OB 82. This OB allows you via according programming to
request detailed diagnostic information by means of the SFCs 51 and 59
and react to it.After the working off of the OB 82, the processing of the user application is
continued. The diagnostic data are consistent until leaving the OB 82.

Error cause	Message	Possible error cause	Remedial
and remedy	External load voltage missing	Load voltage L+ of the module is missing	Proof connections L+ and M, Proof power supply
	Project engineering/ Parameterization error	Wrong parameters have been transferred to the module	Proof parameterization
	Ground short circuit	Output overload	Remove overload
		Short circuit of the output QV after M-	Check load connection for short circuit
	Wire break (only 332-5Hx01)	Line interruption between module and actuator	Check line
		actuator is too high- resistance	Use another actuator type
			Use lines with more core-cross section
		Channel is not used	Deactivate channel in parameterization
	Front switch manual mode (only 332-5HDx0)	Manual intervention by means of the front switch.	switch all by group diagnostics activated switches to <i>automatic</i> <i>operation</i> .

332-5Hx01 - AO 2/4x12Bit U/I

Order data	AO 2x12Bit	VIPA 332-5HB	01		
	AO 4x12Bit	VIPA 332-5HD	001		
Description	Depending on the mo may be parameterized	dule there are up to 4 d individually.	analog outputs which functions		
		provided with externa			
Properties	 4 individual parame (332-5HB01 has 2 	eterizable outputs output channels)			
	 the outputs are parameterizable per channel as voltage output current output deactivated 				
	 usable for actuators with inputs of ±10V, 1 5V, 0 10V, ±20mA, 4 20mA or 0 20mA 				
	 parameterizable diagnostics and diagnostics interrupt 				
	• isolated between b	between backplane bus and load voltage			
Parameterization	After Power ON, the n	nodules have the follo	wing default settings:		
	• Output range: ±10	/ for all channels			
	Interrupts are deac	tivated			
	The modules are to be projected as analog output modules of Siemens in accordance with the following rules:				
	VIPA 332-5HB01	to be configured as	6ES7 332-5HB01-0AB0		
	VIPA 332-5HD01	to be configured as	6ES7 332-5HD01-0AB0		

Note!

The deployment of the module at the active backplane bus is not possible!

Structure





- [1] LEDs
- [2] flap with labeling strip
- [3] contact bar
- [4] flap opened with inner label

Pin assignment

Status monitor



Note!

Please regard, that you must not connect the S-Pin at current output!

Restriction AO 2x12Bit (332-5HB01)

Status monitor via LEDs

Due to the 2 cha	annels of the	module the	channels	CH2 and	CH3 and	the
LEDs Q2, Q3, F2	and F3 are	not available				

LED	Description
SF	Group error:
	On at parameterized group diagnostics, as soon as a diagnostic entry is present.
	On independently from diagnostics at missing external voltage supply
Q0Q3	Channel active
	On when the according output channel has been activated
F0 F3	Channel error
	On together with SF at the according channel with error.

Technical data

Module name	VIPA 332-5HB01	VIPA 332-5HD01	
Dimensions and Weight			
Dimensions (WxHxD)	40x125x120mm		
Weight	20	0g	
Data for Specific Module			
Number of outputs	2	4	
Length of cable: shielded	20	0m	
Programming specifications			
Output data	4byte	8byte	
	(1word each channel)	(1word each channel)	
Parameter data	16t	oyte	
Diagnostic data	16t	oyte	
Voltages, Currents, Potentials			
Rated load voltage L+	DC	24V	
- Reverse polarity protection	ye	es	
Isolation			
 between channels / backplane bus 	ye	es	
- between channels /	ye	es	
Power supply of the electronics			
- between channels	no		
- between channels / load voltage L+	yes		
Permitted potential difference			
- between M _{ANA} and M _{INTERN} (U _{ISO})	DC 75V / AC 60V		
		500V	
- backplane bus	max. 100mA	max. 125mA	
- supply voltage L+ (no load)		max. 115mA	
Power dissipation of the module	typ. 2.5vv	typ. 3,5w	
Analog value generation			
	100#	· · · • •	
$\pm 10V; \pm 20MA$	12Bit + sign		
1 5V; 4 20mA	11Bit		
0 10V; 0 20MA	12Bit		
	U.5ms	Tms	
	U.2MS		
	1.Ums		
- inductive load	1.0ms		

continued ...

... continue

Suppression of interference, Limits of Error	VIPA 332-5HB01	VIPA 332-5HD01	
Crosstalk between outputs	> 40dB		
Operational limit (in the entire temperature range, w	ith reference to the out	put range)	
	Range	Tolerance	
Voltage outputs	1 5V	$\pm 0.8\%^{1)}$	
	0 10V	$\pm 0.4\%^{1}$	
	±10V	±0.2% ¹⁾	
Current outputs	4 20mA	$\pm 0.8\%^{2}$	
	020mA	$\pm 0.6\%^{2}$	
	±20mA	±0.3% ²	
Basic error (operational limit at 25°C, referred to our	tput range)		
	Range	Tolerance	
Voltage outputs	1 5V	$\pm 0.5\%^{1}$	
	0 10V	$\pm 0.2\%^{1}$	
	±10V	$\pm 0.1\%^{1}$	
Current outputs	4 20mA	$\pm 0.5\%^{+1}$	
	0 20mA	$\pm 0.4\%^{(2)}$	
	±20V	$\pm 0.2\%^{2}$	
Temperature error	±0.0	1%/K	
(with reference to the output range)			
Linearity error	±0.	.1%	
(with reference to the output range)		0 = 0/	
Repeatability	±0.05%		
(In steady state at 25°C, referred to output range)	-	/	
Output ripple;	±0.0	05%	
Range U to 50KHZ			
Status Interrunte Diagnostics			
		(
- Diagnostic interrupt	parame	terizable	
Diagnostic functions	parameterizable		
- Group error display	red LED (SF)		
- Error per channel	red LED		
- Diagnostic information readable	possible		
Substitute value can be applied	y.	es	

¹⁾ The error limits were determined with a load R=1G Ω . At voltage output the resistance of output of the module amounts 30 Ω .

 $^{2)}~$ The error limits were determined with a load R=10 $\Omega.$

continued ...

... continue

Data for selecting an actuator	VIPA 332-5HB01	VIPA 332-5HD01	
Output range (nominal value)			
- Voltage	±10V		
	0 10V		
	1	5V	
- Current	±20mA		
	0 2	20mA	
	4 2	20mA	
Load resistance (in nominal range of the output)			
- at voltage outputs	min.	1kΩ	
capacitive load	max.	1μF	
- at current outputs	max.	500Ω	
inductive load	max. 10mH		
Voltage output			
- Short circuit protection	ye	es	
- Short circuit current	30mA		
Current output			
- No-load operation	15	šV	
Destruction limit against voltages/currents			
applied from outside			
- Voltage at outputs to M _{ANA}	max.	15V	
- Current	max. 30mA in	iternal limited	
Connecting of actuators			
- voltage output			
2-conductor connection	possible		
4-conductor connection	possible		
- current output			
2-conductor connection	poss	sible	

332-5HDx0 - AO 4x12Bit for manual operation

Order data	AO 4x12Bit I for manual operation AO 4x12Bit U for manual operation	VIPA 332-5HD50 VIPA 332-5HD60
Description	For each channel there is a 2-pole switc the front side of the two modules. An a potentiometer, which is issued at the c to manual operation. The module has to be provided with extern	ch with associated potentiometer on analog value may be preset by the orresponding channel by switching ernal DC 24V.
Properties	 4 individual parameterizable outputs the outputs are parameterizable per of VIPA 332-5HD50: - Current output 4 - deactivated VIPA 332-5HD60: - voltage output 0 - deactivated usable for actuators with an input of 4 usable for actuators with an input of 0 parameterizable diagnostics and diag 1 switch each channel (Automatic-/Ma 1 potentiometer each channel isolated between backplane bus and status LED for power supply 	channel as: 420mA 010V 4 20mA (VIPA 332-5HD50) 0 10V (VIPA 332-5HD60) nostics interrupt anual operation) load voltage
Parameterization	After Power ON the interrupts are deacti	ivated.

The modules have are to be configured as 6ES7 332-5HD01 from Siemens. More information can be found at chapter "Parameterization - Basics" above.

Structure





- [1] LED L+
- [2] flap with labeling strip
- [3] switch: H/A Manual/Automatic mode
- [4] potentiometer
- [5] contact bar
- [6] flap opened with inner label

Pin assignment Status monitor



LED Description

L+ LED (green) supply voltage is on



Manual operation For each channel there is a 2-pole switch with associated potentiometer on the front side.

The operating mode automatic or manual may be toggled by the switch.

At *manual operation* the module issues the value at the according channel adjusted by the potentiometer.

Depending on the switch position there is the following action:

Front switch	Description
Manual operation	Issues at the output channel the value adjusted by the potentiometer.
H A	Note! As long as the module is supplied with DC24V, in manual operation, independently of the mode of operation of the CPU, the by potentiometer adjusted value is issued at the output channel.
Automatic operation H A	The channel operates as a "normal" analog output channel and can be controlled by PLC program.

Potentiometer



For each channel there is a potentiometer on the front side. Here you can preset an analog value from min. up to max. of the nominal range.

If the potentiometer is turned in the clockwise direction beyond the *max.* position, then the overdrive region is reached. Hardware conditionally an exact marking of the ranges is not possible.

As soon as you turn the switch into position "H" (manual operation), the value adjusted by the potentiometer is issued at the according output channel.

Depending on the module there are the following ranges:

Order no.	Nominal range (min max.)	max. overdrive region
VIPA 332-5HD50	420mA	ca. 24mA
VIPA 332-5HD60	010V	ca. 12V

Channel error by switching to manual operation

The switch to *manual operation* is interpreted as a channel error. The appropriate bit for channel errors in byte 7 of the diagnostics record set 1 is set.

An Interrupt_{going} is only possible if all by group diagnostics activated switches are turned to automatic operation.

More can be found in the chapter "Diagnostics" above.



Danger!

With the modules you can cause a jump in the analog value by means of the switch, independently of the CPU operation mode, as long as the module is power supplied. This could lead to material damage or personal injury!

Technical data

Module name	VIPA 332-	-5HD50	VIPA 332	2-5HD60
Dimensions and Weight				
Dimensions (WxHxD in mm)	40x125x120mm			
Weight	200g			
Data for Specific Module			0	
Number of inputs		4	1	
Length of cable: shielded		200	0m	
Programming specifications	to confi	qure as 6ES	7 332-5HD01-	-0AB0
Output data	81	byte (1word)	each channel)	
Parameter data			, vte	
Diagnostics data		16b	ovte	
Voltages, Currents, Potentials			·	
Rated load voltage L+		DC	24V	
- Reverse polarity protection		ye	es	
Isolation				
- between channels and backplane bus		ye	es	
- between channels and power supply		ýe	es	
of the electronics		-		
 between channels 		n	0	
 between channels and load 		ye	es	
voltage L+				
Permitted potential difference				
- between M _{ANA} and M _{INTERNAL} (U _{ISO})	DC 75V / AC 60V			
Isolation tested with	DC 500V			
Current consumption				
- from the backplane bus	80MA			
- from power supply L+ (no load)		130	mA	
Power dissipation of the module		3.5	5W	
Analog value generation				
Resolution (incl. sign)				
0 10V			12	Bit
4 20mA	12B	it		
Cycle time (all channels)		0.5	ms	
Settling time				
- resistive load	0.5m	าร	1.5	ms
- capacitive load	-		1.5	ms
- inductive load	0.5ms -			
Suppression of interference, Limits of error				
Crosstalk between the outputs > 400B				
Operational limit (in the entire temperature	range, with refe	erence to the	output range)
	Range	Iolerance		
- Vollage outputs	- 4 20mA	-	0 100	±0.4%
- Current outputs	4 2011A	±0.4%	-	-
Basic error (operational limit at 25°C, referr	ed to output rar	nge) Telerenee	Danga	Toloropoo
	Range	Tolerance		
- Vollage output	- 4 20mA	-	0 100	±0.2%
	4 ZUIIIA	IU.270 '	-	-

¹⁾ The error limits were determined with a load R=10 Ω .

continued ...

... continue technical data 332-5HDx0

Temperature error (with reference to the output range)	±0.0	1%/K	
Linearity error	+0 15%		
(with reference to the input range)	±0.		
Reneatability	+0 (15%	
(in steady state at 25°C	10.0	5070	
referred to output range)			
Output ripple:	±0.0)5%	
range 0 to 50kHz			
(referred to output range)			
Status, Interrupt, Diagnostics			
Interrupts			
- Diagnostic interrupt	paramet	terizable	
Diagnostic functions	paramet	terizable	
- Power supply	LED (green)	
- Diagnostic information readable	pos	sible	
Substitute value can be applied	yes		
Data for selecting an actuator			
Output range (rated values)			
- Voltage	-	010V	
- Current	4 20mA -		
Load resistance (in the nominal range of the out	put)		
 for voltage outputs 	-	min. 1k Ω	
capacitive load	-	max. 1µF	
 for current outputs 	max. 500Ω	-	
inductive load	max. 10mH	-	
Voltage outputs			
- Short-circuit protection	-	yes	
- Short-circuit current	-	25mA	
Current outputs			
- No-load voltage	15V -		
Destruction limit against voltage/currents applied	from outside		
- Voltage at outputs to M _{ANA}	max.	. 15V	
- Current	max. 25mA max. 30mA		
Connecting actuators		I	
- tor voltage output			
2-conductor connection	- possible		
- tor current output			
2-conductor connection	possible	-	

Chapter 8 Analog In/Output Modules

Outline This chapter contains a description of the structure and the operation of the VIPA analog in/output modules.

ContentTopicPageChapter 8Analog In/Output Module.8-1System overview8-2Security hint8-2General8-3Analog value representation8-4Parameterization8-6334-0KE00 - Al 4/AO 2x12Bit8-8

System overview

Analog in/output module SM 334

In the following you will get an overview over the analog input/output modules that are available at VIPA:



Order data	Туре	Order number	Page
analog output	AI 4/AO 2x12Bit	VIPA 334-0KE00	8-8
modules			

Security hint



Attention!

Please regard that the module VIPA 334-0KE00 does not have hardware precautions against wrong parameterization. The setting of the according measuring range is exclusively at the project engineering. At the project engineering you should be very careful.

Please regard also that disconnecting res. connecting during operation, the so-called "Hot Swapping", is not possible!

General

Cables for analog signals For analog signals you should use isolated cables to reduce interference. The cable screening should be grounded at both ends. If there are differences in the potential between the cable ends, there may occur a potential compensating current that could disturb the analog signals. In this case you should ground the cable screening only at one end.



Note!

Please take always care of the correct polarity when connecting! Please install short circuits at non-used inputs by connecting the positive contact with the channel ground.

Please leave the output pins of not used channels disconnected and configure the *output type* of the channel to "deactivated".

In this way the cycle time of the module gets shorter.

Parameterization The module may be configured by means of a hardware configuration or rather during run time by SFCs.

After PowerON, the module has the following default settings:

- Input range: Pt100 Climate (RTD-4L)
- Output range: voltage 0 ... 10V

Analog value representation

General As soon as a measuring value exceeds the overdrive res. underdrive range, the following value is returned:

Measuring value > Overdrive range: 32767 (7FFFh)

Measuring value < Underdrive range: -32768 (8000h)

At parameterization error or de-activated analog part the measuring value 32767 (7FFFh) is returned. When leaving the defined range during analog output 0V is issued.

In the following all measuring ranges are specified, which are supported by the analog part. With the formulas it may be converted between measuring and analog value.

Numeric notation The analog values are represented in two's complement format.

in Siemens																
S7 format							A	nalog	g valu	e						
				High	byte							Low	byte			
Bit number	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Resolution	SG		Analog value (word)													
12bit + sign	SG	Rele	vant	outpu	ıt valu	ie								Х	Х	Х

* The least significant irrelevant bits of the output value are marked by "X".

Sign bit (SG) The algebraic sign bit is represented by Bit 15. Here it is essential: Bit $15 = "0" \rightarrow \text{positive value}$ Bit $15 = "1" \rightarrow \text{negative value}$

Voltage measuring	Formulas for th	ne conversion:	
range 0 10V	$Value = 27648 \cdot \frac{U}{10}$, $U = Value \cdot \frac{10}{2764}$	8

U: voltage, Value: decimal value

10	2764	8	
010V	dez.	hex.	Range
> 11.759	32767	7FFFh	Overflow
11.759V	32511	7EFFh	Overdrive range
10V	27648	6C00h	Nominal range
0V	O	0	
Negative value	s not possible		Underdrive range

Resistance measurement R-4L (0 ... 10kΩ) Formulas for the conversion:

 $Value = 27648 \cdot \frac{R}{10000}$, $R = Value \cdot \frac{10000}{27648}$ R: resistance value, Value: decimal value

100	100 2	/048	
10kΩ	dez.	hex.	Range
11.852kΩ	32767	7FFFh	Overflow
	32512	7F00h	
11.759kΩ	32511	7EFFh	Overdrive range
•	27649	6C01h	
10kΩ	27648	6C00h	Nominal range
7.5kΩ	20736	5100h	
361.7mΩ	1	0001h	
0Ω	0	0000h	
Negative values	s physically not	possible	Underdrive range

Resistance thermometer (Pt100 Climate) With Pt 100 the temperature is directly shown with the adjusted unit. Here applies: 1 Digit = 0.01 temperature unit.

Pt100			Pt100			Range
in °C (1digit= 0.01°C)	dec.	hex.	in °F (1digit= 0.01°F)	dec.	hex.	
>155.0	32767	7FFFh	>311.0	32767	7FFFh	Overflow
155.0	15500	3C8Ch	311.0	31100	797Ch : :	Overdrive range
130.0 -120.0	13000 : : -12000	32C8h : : D120h	266.0 -184.0	26600 : : -18400	67E8h · · B820h	Nominal range
: -145.0	: -14500	: C75Ch	: -229.0	: -22900	: A68Ch	Underdrive range
< -145.0	-32768	8000h	<-229.0	-32768	8000h	Underflow

Formulas for the conversion:

Voltage output range 0 ... 10V

<i>Value</i> = 2764	$8 \cdot \frac{U}{10}, \ U = Value \cdot \cdot \cdot$	$\frac{10}{27648}$	U: voltage, Value: decimal value
010V	dez.	hex.	Range
VC	32767	7FFFh	Overflow
	· · · · · · · · · · · · · · · · · · ·	•	
11.76V	32511	7EFFh	Overdrive range
	· ·	•	
10V	27648	6C00h	Nominal range
• •		•	
0V	O	O	
	:		Underdrive range
DV	-6912	E500h	
			Underflow
OV	- -32768	8000h	

Parameterization

Overview	There are the following possibilities for parameterization:
	• Parameterization by hardware configuration of Siemens SIMATIC manager or with WinPLC7 from VIPA.
	 Parameterization during run time by means of SFCs.
Parameterization	To be compatible to the Siemens SIMATIC manager the following steps are to be accomplished:
configuration	Start the hardware configurator from Siemens
	Create a new project
	Configure your CPU.
	• Link-up your System 300V modules in the plugged-in sequence starting with slot 4.
	• Configure the analog in/output module as module from Siemens with the order number 6ES7 334-0KE00-0AB0.
	The analog modules may be found at the hardware catalog at <i>Simatic</i> 300 > <i>SM-300</i> .
	• If needed parameterize the CPU respectively the modules. The parameter window appears as soon as you double click on the according module. At this window the according parameter can be changed.
	• Save your project, switch the CPU to STOP and transfer your project to the CPU. As soon as the CPU is switched to RUN the parameters are transferred to the connected modules.
Parameters	The following parameters may be adjusted at the analog in/output module:
	Starting address of the data
	Input area (de-activated, integration time, measuring type/range)Output area (de-activated, voltage output)
	A closer description of the parameters may be found below.

Parameterization during run time by means of SFCs

If the module gets parameters, which are not supported by the module, these parameters are interpreted as wrong parameters and an error is initialized via the measuring value 32767 (7FFFh).

At the parameterization, a 14byte long parameter area is set in the record set 1. Deploying the SFCs 55, 56 and 57, you may alter parameters during run time and transfer them to the module.

Parameter record set 1

Byte	Bit 7 Bit 0				
0	Bit 7 0: not relevant				
1	Integration time				
	Bit 1, 0: Channel 0	01: 16.6ms			
	Bit 3, 2: Channel 1	10: 20ms			
	Bit 5, 4: Channel 2				
	Bit 7, 6: Channel 3				
2	Measuring channel 0				
	Bit 3 0: Measuring range	weasuring	BIT 74	Measuring	Bit 30
3	Measuring channel 1	iype		range	
5	Bit 3 0. Measuring range	de-activated	0000	de-activated	0000
	Bit 7 4 [·] Measuring type		0000		0000
4	Measuring channel 2	Voltage	0001	0 10V	1000
	Bit 3 0: Measuring range	Resistance	0100	10kΩ	1001
	Bit 7 4: Measuring type	R-4L			
5	Measuring channel 3	Thermo-	1000	Pt100 Climate	0000
	Bit 3 0: Measuring range	meter			
	Bit 7 4: Measuring type	RTD-4L			
6	Output channel 0				
	Bit 3 0: Output range	Output	Bit 74	Output	Bit 30
	Bit 7 4: Output type	type		range	
7	Output channel 1	de estivated	0000	de estivated	0000
	Bit 3 0: Output range	de-activated	0000	de-activated	0000
		Voltage	0001	0 10V	1000
8 13	not relevant				

Voltage measuring Please regard voltage measurement is only possible by channel 2 and 3. via channel 2 and 3

334-0KE00 - AI 4/AO 2x12Bit

Order data	AI 4/AO 2x12Bit	VIPA 334-0KE00	
Description	There are up to 4 analog inp be parameterized by groups The module has to be provid	puts and 2 analog outputs, which functions ma ded with external DC 24V.	łУ
Properties	 4 inputs in 2 groups 2 outputs in one group Measuring type parameter - voltage - resistor - temperature Type of output parameter - voltage isolated between backpla 	erizable per channel rizable per channel group ane bus and load voltage	
Parameterization	After PowerON, the module • Input range: Pt100 Clima • Output range: voltage 0. The module is to be com- number 6ES7 334-0KE00-0.	has the following default settings: te (RTD-4L) 10V figured as module from Siemens with orde AB0.	ər
	Note! The deployment of the mode	ule at the active backplane bus is not possible!	Į
Structure		[1] LEDs	





- [1] LEDs
- [2] flap with labeling strip
- contact bar [3]
- flap opened with [4] inner label

Pin	assignment
	assignment

Pin Circuit diagram

334-0KE00





HB130E - SM - Rev. 10/10

Technical data

Module name	VIPA 334-0KE00
Dimensions and weight	
Dimensions W x H x D	40x125x125
Weight	ca. 200g
Data for specific Module	
Number of inputs	4
- Voltage/current input	2 (voltage)
- for 4-wire resistance-type sensor	4
Number of outputs	2
Length of cable	
- shielded	200m
Programming specifications	
Input data	8byte (1word per channel)
Output data	4byte (1word per channel)
Parameter data	14byte
Diagnostic data	-
Process interrupt data	-
Voltages, Currents, Potentials	
Power supply	DC 24V
- Reverse polarity protection	yes
Constant current for resistance-type sensor	100µA (10k) / 1.6mA (PT100)
Resistance input	7.0V
Isolation	
 between channels and backplane bus 	yes
- between channels and	yes
power supply of the electronics	
- between channels	no
Permitted potential difference	
- between the inputs (U_{CM})	DC 13V
- between M _{ANA} and M _{INTERN} (U _{ISO})	DC 75V / AC 60V
Insulation tested with	DC 500V
Current consumption	
 from the backplane bus (5V) 	90mA
 from supply voltage L+ (DC 24V) 	50mA
Power dissipation of the module	2.0W
Analog value generation of the inputs	
Measuring principle	Sigma-delta
Integration time-/Conversion time/Resolution (per	Channel)
- parameterizable	yes
- basic conversion time	72ms
- resolution (incl. overrange)	12bit
- Noise suppression for	50Hz/60Hz
trequency f1 in Hz	
Basic execution time	nx72ms
Smoothing of the measured values	none

continued ...

Analog value generation of the outputs	
Resolution	
- Voltage 010V 12bit	
Conversion time (per channel) 0.5ms	
Settling time	
- for resistive load 0.8ms	
- for capacitive load 0.8ms	
Suppression of interference, Limits of error of the inputs	
Noise suppression for f=n x (f1 \pm 1%) (f1= interference frequency, n=1,2,)	
- Common mode interference ($U_{CM} < 13V$) > 80dB	
- Series mode noise > 80dB	
(peak value of noise < Nominal value of	
input range)	
Crosstalk between the inputs > 50dB	
Optional limit (in the entire temperature range, with reference to the input range)	
- Voltage input 010V ±0.2%	
- Resistors $010k\Omega \pm 0.8\%$	
- Resistance thermometer Pt100 Climate ±0.7%	
Basic error (operational limit at 25°C, referred to input range)	
- Voltage 010V ±0.1%	
- Resistors $010k\Omega$ $\pm 0.5\%$	
- Resistance thermometer Pt100 Climate ±0.3%	
Temperature error ±0.01%/K	
(with reference to the input range)	
Linearity error ±0.005%	
(with reference to the input range)	
Repeatability ±0.05%	
(in steady state at 25°C, referred to input range)	
Suppression of interference, Limits of error of the outputs	
Crosstalk between outputs > 40dB	
Operational limit (in the entire temperature range, with reference of the output range)	
- Voltage 010V ±0.2%	
Basic error (Operational limit, at 25°C, with reference of the output range)	
- Voltage 010V ±0.1%	
Temperature error ±0.005%/K	
(with reference to the output range)	
Linearity error ±0.1%	
(with reference to the output range)	
Repeatability (in steady state at 25°C, (with ±0.05%	
reference to the output range)	
Output ripple; Range 0 to 50kHz (with reference ±0.05%	
to the output range)	
Status, Interrupt, Diagnostics	
Interrupts none	
Diagnostics functions none	-
Substitute value supported none	

continued ...

continue		
Data for selecting a sensor		
Input range (rated values)/input resistance	Input range	Input resistance
- Voltage	010V	100kΩ
- Resistors	010kΩ	10MΩ
- Resistance thermometer	Pt100	10MΩ
Maximum input voltage for voltage input	30V	
(destruction limit)		
Connection of the sensor		
- for measuring voltage	possible	
- for measuring resistance		
as 2-conductor connection	possible	
as 3-conductor connection	possible	
as 4-conductor connection	p	ossible
Characteristic linearization		
 for resistance thermometer 	Pt100 Climate	
Temperature compensation		no
Technical unit for temperature measurement		C°
Data for selecting an actuator		
Output ranges (rated values)		
- Voltages	(D10V
Load resistance		
(in the nominal range of the outputs)		
 for voltage outputs 	min. 1kΩ	
capacitive load	max. 1µF	
Voltage outputs		
- Short-circuit protection		yes
- Short-circuit current	ma	ax. 20mA
Destruction limit against voltages/currents		
- Voltages at outputs to M _{ANA}	max. 16	/ (30V for 10s)
- Current	not	possible
Connection of actuators		
 for voltage output 		
2-conductor connection	p	ossible
4-conductor connection	not	possible

Appendix

A Index

Α

Analog in/output modules
334-0KE008-8
Connection 8-9
Parameterization
Technical data8-10
Analog value representation 8-4
Numeric notation8-4
Parameterization8-6
during run time8-7
Resolution8-4
Security hint8-2
Signal lines8-3
System overview8-2
Analog input modules
331-1KF016-7
Connection
Parameterization 6-10
Resolution6-9
Technical data6-14
Value representation
331-7Kx016-17
Compensation6-20
Connection6-18
Diagnostics6-29
Error behavior6-23
Parameterization 6-24
Process interrupt 6-33
Pt100 reference junction 6-22
Resolution6-23
Sensors 6-19
Technical data6-35
Trouble shooting6-32
Value representation 6-23
Measuring mode6-6
Parameterization6-4
at run time6-5
Security hint6-2
Signal lines6-3
System overview6-2
Analog output modules7-1
332-5HDx07-18
Connection

Front switch	7-20
Parameterization	7-18
Potentiometer	7-20
Technical data	7-21
332-5Hx01	7-13
Connection	7-14
Parameterization	7-13
Technical data	7-15
Connection	7-4
Diagnostics	7-9
Error behavior	7-12
Manual operation	7-18
Output mode	7-8
Parameterization4-	-18, 7-6
during run time4-	-19, 7-7
Replacement value	7-8
Resolution	7-5
Security hint	7-2
Signal lines	7-3
substitute a value	4-19
System overview	7-2
Trouble shooting	7-12
Value representation	7-5
D	
Digital in-/output modules	5-1
323-1BH00	5-3
323-1BH01	5-5
323-1BL00	5-7
Security hints	5-2
System overview	5-2

322-5FF004-16
Manual operation4-10
Relay output4-21
System overview4-2
R
Resolution of analog values
S
System 300V
Assembly2-1, 2-5
Bus connector2-2
Cabling2-6
Front connectors2-8
Central system1-4
Components1-4

Core cross-section 1-5	5
Decentral system1-4	ł
EMC 2-10)
Basic rules 2-11	
Environmental conditions 1-5	5
Installation dimensions 2-3	3
Installation guidelines 2-1, 2-10)
Interference influences 2-10)
Introduction 1-1	
Isolation of conductors 2-12	2
Overview1-3	3
Peripheral modules 1-4	ł
Safety Information 1-2	2
Structure 2-4	ł

M.Stich